

Uputstvo za upotrebu

ROWENTA stajler za kosu CF4710

Rowenta



Tehnoteka je online destinacija za upoređivanje cena i karakteristika bele tehnike, potrošačke elektronike i IT uređaja kod trgovinskih lanaca i internet prodavnica u Srbiji. Naša stranica vam omogućava da istražite najnovije informacije, detaljne karakteristike i konkurentne cene proizvoda.

Posetite nas i uživajte u ekskluzivnom iskustvu pametne kupovine klikom na link:

<https://tehnoteka.rs/p/rowenta-stajler-za-kosu-cf4710-akcija-cena/>

FR
Le contenu de l'empløi ainsi que les consignes de sécurité avant toute utilisation.

1. CONSEILS DE SÉCURITÉ

- Pour votre sécurité, cet appareil est conforme aux normes et réglementations applicables (Directives Basses Tensions, Compatibilité Electromagnétique, Environment...). Evitez le contact avec les cordons d'alimentation ne soit jamais en contact avec les parties chaudes de l'appareil.

- Vérifiez que la tension de votre installation électrique correspond à celle de votre appareil. Toute erreur de branchement peut causer des dommages irréversibles non couverts par la garantie.

- Pour une protection supplémentaire, l'installation d'un dispositif à courant résiduel (RCD) ayant un courant de fonctionnement résiduel nominal n'excédant pas 30 mA est conseillée dans le circuit électrique alimentant la salle de bain. Demandez conseil à l'installateur.

- Risque de brûlure. Gardez l'appareil hors de portée des jeunes enfants, en particulier pendant l'utilisation et le refroidissement.

- Non-faible l'appareil est connecté à l'alimentation, ne le laissez jamais sans surveillance.

- Placez toujours l'appareil avec le support, le cas échéant, sur une surface plane, stable et résistante à la chaleur.

- L'installation de l'appareil, et son utilisation, doit toujours être conforme aux normes en vigueur dans votre pays.

- **ATTENTION** : ne pas utiliser cet appareil près des baignoires, douches, lavabos ou autres récipients contenant de l'eau.

- Lorsque l'appareil est utilisé dans une salle de bain, débranchez-le après utilisation, car la proximité de l'eau représente un danger, même lorsque l'appareil est éteint.

- Cet appareil peut être utilisé par des enfants âgés de 8 ans et plus et des personnes ayant des capacités physiques, sensorielles ou mentales réduites ou un manque d'expérience et de connaissances, s'ils ont reçu un encadrement ou des instructions concernant l'utilisation de l'appareil en toute sécurité et comprennent les risques encourus.

- Les enfants ne doivent pas jouer avec l'appareil. Les enfants ne doivent ni nettoyer l'appareil ni s'occuper de son entretien sans surveillance.

- Danger de brûlure. Conserver l'appareil hors de portée des jeunes enfants, en particulier lors de son utilisation l'utilisation de l'appareil.

- Lorsque l'appareil est raccorder à l'alimentation, ne jamais le laisser sans surveillance.

- Toujours placer l'appareil avec le support, s'il existe, sur une surface plate stable, résistante à la chaleur.

- Si le câble d'alimentation est endommagé, il doit être remplacé par le fabricant ou une personne apte-venue ou une personne de qualification similaire, afin d'éviter un danger.

- Ne pas utiliser si l'appareil est endommagé ou si la notice de sécurité n'est pas correctement tombé, s'il ne fonctionne pas normalement.

- L'appareil est équipé d'un système de sécurité thermique. En cas de surchauffe, l'appareil s'arrêtera automatiquement: contactez le SAV.

- L'appareil doit être débranché avant le nettoyage et l'entretien, en cas d'anomalie de fonctionnement, dès que vous avez terminé de l'utiliser.

- Attention: toujours débrancher l'appareil et le laisser refroidir avant de le nettoyer.

- Nettoyer le fer à l'aide d'un chiffon doux humide et le sécher avec un chiffon sec.

- Laisser le fer à chaud. Ne jamais le laisser refroidir avec l'eau.

- Ne pas fumer ni passer sous l'eau, même pour le nettoyage.

- Ne pas tenir avec les mains humides.

- Ne pas tenir par le boîtier qui est chaud, mais par la poignée.

- Ne pas débrancher le fer de la prise électrique sans en tirer par la prise.

- Ne pas utiliser de prolongateur électrique.

- Ne pas nettoyer avec des produits abrasifs ou corrosifs.

- Ne pas utiliser sur température inférieure à 0 ° C et supérieure à 35 ° C.

- Ne pas utiliser sur cheveux mouillés.

GARANTIE

Votre appareil est destiné à un usage domestique seulement. Il ne peut être utilisé à des fins professionnelles. La garantie devient nulle et invalide en cas d'utilisation incorrecte.

2. UTILISATION

- Prendre une mèche de cheveux et la placer entre les plaques.

- Refermer le fer sur la mèche en maintenant une pression durable quelques secondes et reproduire le geste jusqu'à la pointe. (Se référer au guide d'utilisation pour l'effet souhaité).

- Recomencer l'opération sur toute la chevelure.

- Pour un effet plus naturel, passer des doigts plusieurs fois dans la chevelure.

- Une fois l'utilisation terminée, passer l'appareil du côté de la coque thermo-protectrice.

PARTICIPIANS À LA PROTECTION DE L'ENVIRONNEMENT

☑ Votre appareil contient de nombreux matériaux valorisables ou recyclables. Confiez celui-ci dans un point de collecte ou à défaut dans un centre service agréé pour que son traitement soit effectué.

☑ Cet appareil est conforme aux normes européennes en matière de recyclage.

☑ L'absence de pictogramme de danger indique que votre appareil est exempt de substances dangereuses.

Ces instructions sont également disponibles sur notre site Internet www.rowenta.com.

EN
Read the instructions carefully as well as the safety guidelines before use.

1. SAFETY INSTRUCTIONS

- For your safety, this appliance complies with the applicable standards and regulations (Low Voltage Directive, Electromagnetic Compatibility, Environment...).

- Avoid contact with the skin. Make sure that the supply cord never comes into contact with the hot parts of the appliance.

- Check that the voltage of your electricity supply matches the voltage of your appliance.

- Any error when connecting the appliance can cause irreparable harm, not covered by the warranty.

- For additional protection, the installation of a residual current device (RCD) having a rated residual operating current not exceeding 30 mA is advisable in the electrical circuit supplying the bathroom. Ask for installer for advice.

- Always place the appliance on a heat-resistant, stable flat surface.

- The installation of the appliance and its use must however comply with the standards in force in your country.

- **WARNING:** do not use this appliance near bathtubs, showers, basins or other receptacles containing water.

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning its use by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

- When the appliance is used in a bathroom, unplug it after use since the proximity of water presents a hazard even when the appliance is switched off.

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning its use by a person responsible for their safety.

- Always place the device using the stand, where applicable, on a flat, stable, heat-resistant surface.

- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

- Stop using your appliance and contact an Authorised Service Centre if:

- your appliance has fallen.
- it does not work correctly.
- The appliance is equipped with a heat-sensitive safety device. In the event of overheating, the dryer will stop automatically: contact the After-Sales Service.
- The appliance must be unplugged.
- before cleaning and maintenance procedures.
- if it is not working correctly.
- as soon as you have finished using it.

- If you leave the room, even momentarily.

- Do not touch the appliance when it is plugged in and allow it to cool before cleaning it.

- Always place the device using the stand, where applicable, on a flat, stable, heat-resistant surface.

- Do not use it with the cord damaged. It must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

- Stop using your appliance and contact an Authorised Service Centre if:

- your appliance has fallen.
- it does not work correctly.
- The appliance is equipped with a heat-sensitive safety device. In the event of overheating, the dryer will stop automatically: contact the After-Sales Service.
- The appliance must be unplugged.
- before cleaning and maintenance procedures.
- if it is not working correctly.
- as soon as you have finished using it.

- If you leave the room, even momentarily.

- Do not touch the appliance when it is plugged in and allow it to cool before cleaning it.

- Always place the device using the stand, where applicable, on a flat, stable, heat-resistant surface.

- Do not use it with the cord damaged. It must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

- Stop using your appliance and contact an Authorised Service Centre if:

- your appliance has fallen.
- it does not work correctly.
- The appliance is equipped with a heat-sensitive safety device. In the event of overheating, the dryer will stop automatically: contact the After-Sales Service.
- The appliance must be unplugged.
- before cleaning and maintenance procedures.
- if it is not working correctly.
- as soon as you have finished using it.

- If you leave the room, even momentarily.

- Do not touch the appliance when it is plugged in and allow it to cool before cleaning it.

- Always place the device using the stand, where applicable, on a flat, stable, heat-resistant surface.

- Do not use it with the cord damaged. It must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

- Stop using your appliance and contact an Authorised Service Centre if:

- your appliance has fallen.
- it does not work correctly.
- The appliance is equipped with a heat-sensitive safety device. In the event of overheating, the dryer will stop automatically: contact the After-Sales Service.
- The appliance must be unplugged.
- before cleaning and maintenance procedures.
- if it is not working correctly.
- as soon as you have finished using it.

- If you leave the room, even momentarily.

- Do not touch the appliance when it is plugged in and allow it to cool before cleaning it.

- Always place the device using the stand, where applicable, on a flat, stable, heat-resistant surface.

- Do not use it with the cord damaged. It must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

- Stop using your appliance and contact an Authorised Service Centre if:

- your appliance has fallen.
- it does not work correctly.
- The appliance is equipped with a heat-sensitive safety device. In the event of overheating, the dryer will stop automatically: contact the After-Sales Service.
- The appliance must be unplugged.
- before cleaning and maintenance procedures.
- if it is not working correctly.
- as soon as you have finished using it.

- If you leave the room, even momentarily.

- Do not touch the appliance when it is plugged in and allow it to cool before cleaning it.

- Always place the device using the stand, where applicable, on a flat, stable, heat-resistant surface.

- Do not use it with the cord damaged. It must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

- Stop using your appliance and contact an Authorised Service Centre if:

- your appliance has fallen.
- it does not work correctly.
- The appliance is equipped with a heat-sensitive safety device. In the event of overheating, the dryer will stop automatically: contact the After-Sales Service.
- The appliance must be unplugged.
- before cleaning and maintenance procedures.
- if it is not working correctly.
- as soon as you have finished using it.

- If you leave the room, even momentarily.

- Do not touch the appliance when it is plugged in and allow it to cool before cleaning it.

- Always place the device using the stand, where applicable, on a flat, stable, heat-resistant surface.

- Do not use it with the cord damaged. It must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

- Stop using your appliance and contact an Authorised Service Centre if:

- your appliance has fallen.
- it does not work correctly.
- The appliance is equipped with a heat-sensitive safety device. In the event of overheating, the dryer will stop automatically: contact the After-Sales Service.
- The appliance must be unplugged.
- before cleaning and maintenance procedures.
- if it is not working correctly.
- as soon as you have finished using it.

- If you leave the room, even momentarily.

- Do not touch the appliance when it is plugged in and allow it to cool before cleaning it.

- Always place the device using the stand, where applicable, on a flat, stable, heat-resistant surface.

- Do not use it with the cord damaged. It must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

- Stop using your appliance and contact an Authorised Service Centre if:

- your appliance has fallen.
- it does not work correctly.
- The appliance is equipped with a heat-sensitive safety device. In the event of overheating, the dryer will stop automatically: contact the After-Sales Service.
- The appliance must be unplugged.
- before cleaning and maintenance procedures.
- if it is not working correctly.
- as soon as you have finished using it.

- If you leave the room, even momentarily.

- Do not touch the appliance when it is plugged in and allow it to cool before cleaning it.

- Always place the device using the stand, where applicable, on a flat, stable, heat-resistant surface.

- Do not use it with the cord damaged. It must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

- Stop using your appliance and contact an Authorised Service Centre if:

- your appliance has fallen.
- it does not work correctly.
- The appliance is equipped with a heat-sensitive safety device. In the event of overheating, the dryer will stop automatically: contact the After-Sales Service.
- The appliance must be unplugged.
- before cleaning and maintenance procedures.
- if it is not working correctly.
- as soon as you have finished using it.

- If you leave the room, even momentarily.

- Do not touch the appliance when it is plugged in and allow it to cool before cleaning it.

- Always place the device using the stand, where applicable, on a flat, stable, heat-resistant surface.

- Do not use it with the cord damaged. It must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

- Stop using your appliance and contact an Authorised Service Centre if:

- your appliance has fallen.
- it does not work correctly.
- The appliance is equipped with a heat-sensitive safety device. In the event of overheating, the dryer will stop automatically: contact the After-Sales Service.
- The appliance must be unplugged.
- before cleaning and maintenance procedures.
- if it is not working correctly.
- as soon as you have finished using it.

- If you leave the room, even momentarily.

- Do not touch the appliance when it is plugged in and allow it to cool before cleaning it.

- Always place the device using the stand, where applicable, on a flat, stable, heat-resistant surface.

- Do not use it with the cord damaged. It must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

- Stop using your appliance and contact an Authorised Service Centre if:

- your appliance has fallen.
- it does not work correctly.
- The appliance is equipped with a heat-sensitive safety device. In the event of overheating, the dryer will stop automatically: contact the After-Sales Service.
- The appliance must be unplugged.
- before cleaning and maintenance procedures.
- if it is not working correctly.
- as soon as you have finished using it.

- If you leave the room, even momentarily.

- Do not touch the appliance when it is plugged in and allow it to cool before cleaning it.

- Always place the device using the stand, where applicable, on a flat, stable, heat-resistant surface.

- Do not use it with the cord damaged. It must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

- Stop using your appliance and contact an Authorised Service Centre if:

- your appliance has fallen.
- it does not work correctly.
- The appliance is equipped with a heat-sensitive safety device. In the event of overheating, the dryer will stop automatically: contact the After-Sales Service.
- The appliance must be unplugged.
- before cleaning and maintenance procedures.
- if it is not working correctly.
- as soon as you have finished using it.

- If you leave the room, even momentarily.

- Do not touch the appliance when it is plugged in and allow it to cool before cleaning it.

- Always place the device using the stand, where applicable, on a flat, stable, heat-resistant surface.

- Do not use it with the cord damaged. It must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

- Stop using your appliance and contact an Authorised Service Centre if:

- your appliance has fallen.
- it does not work correctly.
- The appliance is equipped with a heat-sensitive safety device. In the event of overheating, the dryer will stop automatically: contact the After-Sales Service.
- The appliance must be unplugged.
- before cleaning and maintenance procedures.
- if it is not working correctly.
- as soon as you have finished using it.

- If you leave the room, even momentarily.

- Do not touch the appliance when it is plugged in and allow it to cool before cleaning it.

- Always place the device using the stand, where applicable, on a flat, stable, heat-resistant surface.

- Do not use it with the cord damaged. It must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

- Stop using your appliance and contact an Authorised Service Centre if:

- your appliance has fallen.
- it does not work correctly.
- The appliance is equipped with a heat-sensitive safety device. In the event of overheating, the dryer will stop automatically: contact the After-Sales Service.
- The appliance must be unplugged.
- before cleaning and maintenance procedures.
- if it is not working correctly.
- as soon as you have finished using it.

- If you leave the room, even momentarily.

- Do not touch the appliance when it is plugged in and allow it to cool before cleaning it.

- Always place the device using the stand, where applicable, on a flat, stable, heat-resistant surface.

- Do not use it with the cord damaged. It must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

- Stop using your appliance and contact an Authorised Service Centre if:

- your appliance has fallen.
- it does not work correctly.
- The appliance is equipped with a heat-sensitive safety device. In the event of overheating, the dryer will stop automatically: contact the After-Sales Service.
- The appliance must be unplugged.
- before cleaning and maintenance procedures.
- if it is not working correctly.
- as soon as you have finished using it.

- If you leave the room, even momentarily.

- Do not touch the appliance when it is plugged in and allow it to cool before cleaning it.

ENVIRONMENT PROTECTION FIRST!

☑ Your appliance contains valuable materials which can be recovered or re-cycled.

Leave it at a local civic waste collection point.

These instructions are also available on our website www.rowenta.com.

DE
Lesen Sie die Gebrauchsanleitung sorgfältig vor der ersten Inbetriebnahme Ihres Gerätes durch. Eine unsachgemäße Bedienung emndnet den Hersteller von jeglicher Haftung.

1. SICHERHEITSHINWEISE

- Um Ihre Sicherheit zu gewährleisten, entspricht dieses Gerät den gültigen Normen und Bestimmungen (Niederspannung, elektromagnetische Verträglichkeit, Umwelt...).

- Vermeiden Sie es, sie mit der Haut in Kontakt zu bringen. Vermeiden Sie sich, das Stromkabel nicht mit heißen Teilen des Geräts in Kontakt gerät.

- Überprüfen Sie, dass die Betriebsspannung Ihres Geräts mit der Spannung Ihrer Elektroinstallation übereinstimmt. Ein fehlerhafter Anschluss kann irreparable Schäden hervorufen, die nicht von der Garantie abgedeckt sind.

- Zum Zustellungszeitpunkt sollte das Gerät an den Stromkreis des Badezimmer mit einer Fehlerstrom-Schutzleinste für Wechselstrom mit 30 mA Nennstromförm angeschlossen werden. Lassen Sie sich von Ihrem Elektroinstallateur beraten.

- Geben Sie immer mit dem Ständer, sofern vorhanden, auf eine hitzebeständige, feste, ebene Oberfläche stellen.

- Die Installation des Geräts muss nicht in Ihrem Land gültigen Normen entsprechen.

- **WARNHINWEIS:** Verwenden Sie dieses Gerät nicht in der Nähe einer Badewanne, einer Dusche, eines Waschbeckens oder eines sonstigen Behälters, der Wasser enthält.

- Wenn das Gerät in einem Badezimmer eingesetzt wird, muss es nach dem Gebrauch ausgesteckt werden, da die Nähe von Wasser selbst bei ausgeschaltetem Gerät eine Gefahrenquelle darstellen kann.

- Dieses Gerät darf nicht von Personen (inbegriffen Kindern) mit eingeschränkter körperlicher, sensorischer oder geistigen Fähigkeiten benutzt werden. Das Gültige gilt für Personen, die keine Erfahrung mit dem Gerät besitzen oder sich ihm nicht auskennen, außer wenn sie von einer für Ihre Sicherheit verantwortlichen Person beaufsichtigt werden, oder von dieser mit dem Gebrauch des Gerätes vertraut gemacht werden. Kinder müssen beaufsichtigt werden, damit sie nicht mit dem Gerät spielen.

- Das Gerät darf von Kindern ab 8 Jahren und Personen, deren körperliche oder geistige Unversehrtheit oder deren Wahrnehmungsfähigkeit eingeschränkt ist, nicht benutzt werden.

- Wenn das Stromkabel beschädigt ist, darf es, um jedwede Gefahr zu vermeiden, nur von Hersteller, dem Kundendienst oder ähnlich qualifizierten Personen ausgetauscht werden.

- Dieses Gerät darf nicht von Personen (inbegriffen Kindern) mit eingeschränkter körperlicher, sensorischer oder geistigen Fähigkeiten benutzt werden. Das Gültige gilt für Personen, die keine Erfahrung mit dem Gerät besitzen oder sich ihm nicht auskennen, außer wenn sie von einer für Ihre Sicherheit verantwortlichen Person beaufsichtigt werden, oder von dieser mit dem Gebrauch des Gerätes vertraut gemacht werden. Kinder müssen beaufsichtigt werden, damit sie nicht mit dem Gerät spielen.

- Das Gerät darf von Kindern ab 8 Jahren und Personen, deren körperliche oder geistige Unversehrtheit oder deren Wahrnehmungsfähigkeit eingeschränkt ist, nicht benutzt werden.

- Wenn das Stromkabel beschädigt ist, darf es, um jedwede Gefahr zu vermeiden, nur von Hersteller, dem Kundendienst oder ähnlich qualifizierten Personen ausgetauscht werden.

- Verbernungsfähigkeit: Halten Sie das Gerät außer Reichweite von kleinen Kindern, insbesondere während des Gebrauchs und des Aufräumens.

- Lassen Sie das Gerät niemals unbeaufsichtigt, wenn es mit einer Steckdose verbunden ist.

- Stellen Sie das Gerät immer auf den Ständer, sofern zutreffend, auf eine ebene, feste, hitzebeständige Fläche.

- Benutzen Sie das Gerät nicht und treten Sie auf einem zugelasenen Kundenstellchen in Kontakt, wenn: das Gerät zu Boden gefallen ist und nicht richtig funktioniert.

- Das Gerät ist mit einem Überhitzungsschutz ausgestattet. Bei Überhitzung schaltet das Gerät automatisch aus. Treten Sie in diesem Fall mit dem Kundendienst in Verbindung. Das Ansauggerät darf niemals abgedeckt werden. Reinigen Sie von Zeit zu Zeit das Ansauggerät um ein überhitztes des Gerätes zu vermeiden.

- Das Gerät muss ausgesteckt werden: vor Reinigung und Wartung, bei Funktionstörungen und sofort nach dem Gebrauch. Lassen Sie das Kabel niemals herum hängen, oder in der Nähe von, oder in Berührung mit einer Wärmepumpe, sich drehende Teile oder einer scharfen Kante kommen.

- **ACHTUNG!** Das Gerät vor dem Reinigen immer ausstecken und abkühlen lassen.

- Reinigung des Geräts: Das Gerät ausstecken, mit einem feuchten Lappen säubern und mit einem trockenen Lappen trocken.

- Wenn das Stromkabel beschädigt ist, darf das Gerät nicht benutzt werden.

- Nicht ins Wasser tauchen und nicht unter fließendes Wasser halten, auch nicht zur Reinigung.

- Fassen Sie das Gerät nicht mit feuchten Händen an oder wenn Sie barfuß sind.

- Stecken Sie das Gerät nicht durch Ziehen am Stromkabel aus, sondern ziehen Sie den Stecker aus der Steckdose.

- Benutzen Sie kein Verengungsgerät.

- Reinigen Sie das Gerät nicht mit schwebenden oder ätzenden Produkten.

- Betreten Sie das Gerät nicht bei Temperaturen unter 0 ° C oder über 35 ° C. Legen Sie das Gerät nicht an, solange es eingeschaltet ist. Das Ansauggerät darf niemals abgedeckt werden. Reinigen Sie von Zeit zu Zeit das Ansauggerät um ein überhitztes des Gerätes zu vermeiden. Verwenden Sie nur original Zubehör. Das Gerät nie unbeaufsichtigt lassen.

- Nicht auf nassem Haar verwenden.

GARANTIE

Jeder Eingriff, außer der im Haushalt üblichen Reinigung und Pflege durch den Kunden, muss durch den Kundendienst erfolgen. Dieses Gerät ist ausschließlich für den Hausgebrauch bestimmt. Es darf nicht für gewerbliche Zwecke eingesetzt werden. Bei unsachgemäßer Benutzung erlischt die Garantie.

2. ANWENDUNG

- Nehmen Sie eine Haarsträhne und legen Sie diese zwischen die Platten.

- Schließen Sie das Glättisen und über Sie einige Sekunden lang Druck darauf aus und fahren Sie auf diese Weise bis zu den Haarspitzen fort. (Lesen Sie die Bedienungsanleitung, um die gewünschte Wirkung zu erzielen).

- Wiederholen Sie die oben beschriebenen Schritte mit allen Haarsträhnen.

- Um einen natürlichen Effekt zu erzielen, fahren Sie mehrmals mit den Fingern durch das Haar.

- Wenn Sie fertig sind, stellen Sie das Gerät neben die hitzegeschützte Hülle.

BEDEUTUNG DES SYMBOLS „DURCHGESCHENNE MILCHTÖPFE“

☑ Das auf Elektro- und Elektronikgeräten regelmäßig abgebildete Symbol einer durchgeschrittenen Milchtülle weist darauf hin, dass das jeweilige Gerät ein für die Umwelt schädliches Gas enthält.

☑ Die getrennte Erfassung eines Haushaltsgerätes vermeidet mögliche negative Auswirkungen auf die Umwelt und die menschliche Gesundheit, die durch eine nicht wirtschaftliche Entsorgung bedingt sind. Zudem ermöglicht wird die Wiederverwertung der Materialien, aus denen sich das Gerät zusammensetzt, was wiederum eine bedeutende Einsparung an Energie und Ressourcen mit sich bringt.

- Enthalten die Produkte Batterien und Akkus oder Lampen, die aus dem Altgerät zurückgewonnen werden können, sind Sie als Ersatzteile separat zu entsorgen. Es verpflichtet, diese bei der Entsorgung zu entnehmen und getrennt als Batterie bzw. Lampe zu entsorgen.

MÖGLICHKEITEN DER RÜCKGABE VON ALTGERÄTEN

Besitzer von Altgeräten aus privaten Haushalten können diese bei den Sammelstellen der öffentlich-rechtlichen Entsorgungsträger oder bei den Herstellern oder Vertreibern im Sinne des Elektro- und Elektronik-Recyclinggesetzes unentgeltlich abgeben. Auskünfte zur nächsten Abfallmängelleiste erhalten Sie beim Hersteller oder Händler

Ovaj dokument je originalno proizveden i objavljen od strane proizvođača, brenda Rowenta, i preuzet je sa njihove zvanične stranice. S obzirom na ovu činjenicu, Tehnoteka ističe da ne preuzima odgovornost za tačnost, celovitost ili pouzdanost informacija, podataka, mišljenja, saveta ili izjava sadržanih u ovom dokumentu.

Napominjemo da Tehnoteka nema ovlašćenje da izvrši bilo kakve izmene ili dopune na ovom dokumentu, stoga nismo odgovorni za eventualne greške, propuste ili netačnosti koje se mogu naći unutar njega. Tehnoteka ne odgovara za štetu nanесenu korisnicima pri upotrebi netačnih podataka. Ukoliko imate dodatna pitanja o proizvodu, ljubazno vas molimo da kontaktirate direktno proizvođača kako biste dobili sve detaljne informacije.

Za najnovije informacije o ceni, dostupnim akcijama i tehničkim karakteristikama proizvoda koji se pominje u ovom dokumentu, molimo posetite našu stranicu klikom na sledeći link:

<https://tehnoteka.rs/p/rowenta-stajler-za-kosu-cf4710-akcija-cena/>