

Uputstvo za upotrebu

TEFAL friteza FR495070

Tefal®



Tehnoteka je online destinacija za upoređivanje cena i karakteristika bele tehnike, potrošačke elektronike i IT uređaja kod trgovinskih lanaca i internet prodavnica u Srbiji. Naša stranica vam omogućava da istražite najnovije informacije, detaljne karakteristike i konkurentne cene proizvoda.

Posetite nas i uživajte u ekskluzivnom iskustvu pametne kupovine klikom na link:




<https://tehnoteka.rs/p/tefal-friteza-fr495070-akcija-cena/>


Tefal®

VERSALIO DELUXE




www.tefal.com







1




2



1




3



4



5




6



7



8



9



10


2



Fry



Deep fry



Fry

0,5 L




Deep fry


2 L



11



12



13




Fry

< 0,5 L



Deep fry

1 L → 2 L




14


3



Deep fry



Max 1000 g



15


16

17

* * *



Max 750 g



18

19

20




21

22

23



Deep fry




24




25




26




27




28




29



30



31






32



33



34









5 Deep fry / 180 °C



Deep fry








 2 L maxi			
	1000 g	15-16 min	4
	550 g	10-11 min	
	750 g	13-14 min	
	400 g	7-8 min	



6 Fry / 160 °C



Fry

 0,5 L maxi		
	15 min	4
	30 min	6



7 Sauté / 130 °C



Sauté

x1	10 min	4




8 Simmer / 100 °C



Simmer

30 min	4



9 Boil/Pasta



Boil/Pasta

30 min	4



10 Rice/Risotto



Rice/Risotto

15 min	4




11**Braise**



Braise

40
min


4

52






53




54



55




56




57




58



59



60



61







62



63



64






76



77



78

79

Ovaj dokument je originalno proizveden i objavljen od strane proizvođača, brenda Tefal, i preuzet je sa njihove zvanične stranice. S obzirom na ovu činjenicu, Tehnoteka ističe da ne preuzima odgovornost za tačnost, celovitost ili pouzdanost informacija, podataka, mišljenja, saveta ili izjava sadržanih u ovom dokumentu.

Napominjemo da Tehnoteka nema ovlašćenje da izvrši bilo kakve izmene ili dopune na ovom dokumentu, stoga nismo odgovorni za eventualne greške, propuste ili netačnosti koje se mogu naći unutar njega. Tehnoteka ne odgovara za štetu nanесenu korisnicima pri upotrebi netačnih podataka. Ukoliko imate dodatna pitanja o proizvodu, ljubazno vas molimo da kontaktirate direktno proizvođača kako biste dobili sve detaljne informacije.

Za najnovije informacije o ceni, dostupnim akcijama i tehničkim karakteristikama proizvoda koji se pominje u ovom dokumentu, molimo posetite našu stranicu klikom na sledeći link:

<https://tehnoteka.rs/p/tefal-friteza-fr495070-akcija-cena/>