

## Uputstvo za upotrebu (EN)

ENERGY SISTEM slušalice Style 1 Snow bele

ENERGY  SISTEM



Tehnoteka je online destinacija za upoređivanje cena i karakteristika bele tehnike, potrošačke elektronike i IT uređaja kod trgovinskih lanaca i internet prodavnica u Srbiji. Naša stranica vam omogućava da istražite najnovije informacije, detaljne karakteristike i konkurentne cene proizvoda.

Posetite nas i uživajte u ekskluzivnom iskustvu pametne kupovine klikom na link:

<https://tehnoteka.rs/p/energy-sistem-slusalice-style-1-snow-bele-akcija-cena/>

## ENGLISH

<b>Introduction</b> .....	3
<b>Care and maintenance</b> .....	3
<b>Features</b> .....	3
Connectivity .....	3
Drivers .....	4
Microphone .....	4
Battery .....	4
<b>Product content</b> .....	4
<b>General overview</b> .....	4
<b>Main Functions</b> .....	5
Switching on the device .....	5
Switching off the device .....	5
Charging the battery .....	5
<b>Bluetooth® pairing</b> .....	5
Auto power off function .....	5
<b>Playback control</b> .....	5
Play/Pause .....	5
Volume +/Volume - .....	5
Skipping to the next/previous track .....	5
<b>Call control</b> .....	5
Answering/Ending a call .....	5
Rejecting a call .....	5
<b>Voice Assistant</b> .....	5
<b>Warranty</b> .....	6
<b>Trademarks</b> .....	6
<b>Declaration of conformity</b> .....	6





## Introduction

- Thank you for trusting our company and buying the new *Earphones Bluetooth® Style 1*. We hope you enjoy the product.
- We recommend reading this manual before you start using your *Earphones Bluetooth® Style 1*.

## Care and maintenance

- Do not expose your *Earphones Bluetooth® Style 1* to impacts, dust, humidity or high temperatures.
- Do not use neither corrosive nor abrasive cleaning products.
- Keep the earphones clean and free of dust using a soft, dry cloth.
- Do not dismantle the device. All repair works should be carried out exclusively by qualified staff of Energy Sistem Technology, S.A.
- Please make sure your *Earphones Bluetooth® Style 1* are off when you are not using them. Do not let them completely discharged for a long time.

## Features

### Connectivity

- Bluetooth® 5.1 wireless technology

- Supports HSP / HFP / A2DP / AVRCP protocols
- Compatible with SBC codecs
- Multipoint connection
- Range: 20 m
- Frequency band: 2.4 GHz
- Maximum output power: <20 dBm

#### Drivers

- Frequency response: 20 - 20,000 Hz
- Driver diameter: 14 mm
- Maximum power: 5 mW
- Type: dynamic
- THD: < 1%

#### Microphone

- Sensitivity: -42 dB ± 3 dB (@1 kHz)

#### Battery

- Capacity: 100 mAh / 3.7 V
- Type: lithium-polymer battery
- Battery life: 8 hours\*
- Charging port: USB Type-C
- Charging time: 2 hours

**Note:** Approximate battery life at a medium volume level. Higher volume means higher battery consumption.


### Product content

---

- Earphones Bluetooth® Style 1
- USB Type-C charging cable

### General overview

---



1. Volume +
2. Multifunction button
3. Volume -
4. USB charging port
5. LED indicator
6. Microphone

## Main Functions

---

### Switching on the device

Press and hold the *Multifunction button (2)* for 2 seconds to switch on the device. The *LED indicator (5)* will light up blue and you will hear a confirmation sound.

### Switching off the device

To switch off the device, press and hold the *Multifunction button (2)* for 3 seconds. The *LED indicator (5)* will glow red for 2 seconds and you will hear a confirmation sound.

### Charging the battery

When the battery level of your *Earphones Bluetooth® Style 1* is low, you will hear a warning sound and the *LED indicator (5)* will flash red. Connect the *charging cable* to the *USB charging port (4)*.

The *LED indicator (5)* glows red while charging the battery and turns blue once the battery is fully charged. The charging process takes approximately two hours.

**Important:** We recommend not leaving your *Earphones Bluetooth® Style 1* unused for long periods of time with an empty battery. We advise you to charge the earphones' battery at least once a month.

## Bluetooth® pairing

---

Switch off the *Earphones Bluetooth® Style 1* and press and hold the *Multifunction button (2)* for approximately 4 seconds, until the *LED indicator (5)* starts flashing blue. Your earphones enter search mode, meaning you can pair them with your source device. Select *Earphones Bluetooth® Style 1* on your device screen and press "connect". Both devices will be connected immediately and without codes. You will hear a confirmation sound when both devices are paired.

If you previously paired the earphones with a device, there is no need to repeat the pairing process. Just switch on your *Earphones Bluetooth® Style 1* and enable the Bluetooth connection on your smartphone, tablet, laptop, etc.

### Auto power off function

To optimise battery life, the *Earphones Bluetooth® Style 1* turn off automatically after 5 minutes in Bluetooth search mode, if not synchronised with any other device.

## Playback control

---

### Play/Pause

Press the *Multifunction button (2)* to pause or resume playback.

### Volume +/Volume -

Press *Volume + (1)* to turn up the volume or *Volume - (3)* to turn it down.

### Skipping to the next/previous track

Press and hold *Volume + (1)* to skip to the next track or *Volume - (3)* to switch to the previous track during music playback.

## Call control

---

Once the *Earphones Bluetooth® Style 1* and your smartphone are synchronised, you can control calls from the earphones.

### Answering/Ending a call

To answer an incoming call or hang up, press the *Multifunction button (2)* once.

### Rejecting a call

Press and hold the *Multifunction button (2)* for 2 seconds.

## Voice Assistant

---

Press the *Multifunction button (2)* twice while playback is paused.

## Warranty

---

Find the full warranty terms and conditions at:

<https://www.energysistem.com/terms-warranty>

## Trademarks

---

All company, brand and product names are trademarks or registered trademarks of their respective companies. Specifications are subject to change without notice.

© 2022 by Energy Sistem Technology, S.A. All rights reserved.

## Declaration of conformity

---

Issuer's name: Energy Sistem Technology, S.A. - CIF: A53107488

Address: C/ Calpe, 1 - 03509 Finestrat, Alicante (Spain)

We declare under our sole and exclusive responsibility that the product:

Description: Bluetooth® earphones

Brand: Energy Sistem

Model: Earphones Bluetooth® Style 1

Manufacturer: Energy Sistem Technology, S.A.

Manufacturing country: China

referred to in this declaration complies with the essential norms and standards

- EN 50663:2017
- EN 62479:2010
- EN 62368-1:2014+A11:2017
- EN 301 489-17 V3.2.2 (2019-12)
- EN 301 489-1 V2.2.3 (2019-11)
- EN 300 328 V2.2.2 (2019-07)

in conformity with the provisions of the Directive 2014/53/EU of the European Parliament and of the Council of 16th April 2014.

Finestrat, 1st June 2022



Miguel Ángel Aragüez García  
Innovation and Technology Director



Ovaj dokument je originalno proizveden i objavljen od strane proizvođača, brenda Energy Sistem, i preuzet je sa njihove zvanične stranice. S obzirom na ovu činjenicu, Tehnoteka ističe da ne preuzima odgovornost za tačnost, celovitost ili pouzdanost informacija, podataka, mišljenja, saveta ili izjava sadržanih u ovom dokumentu.

Napominjemo da Tehnoteka nema ovlašćenje da izvrši bilo kakve izmene ili dopune na ovom dokumentu, stoga nismo odgovorni za eventualne greške, propuste ili netačnosti koje se mogu naći unutar njega. Tehnoteka ne odgovara za štetu nanесenu korisnicima pri upotrebi netačnih podataka. Ukoliko imate dodatna pitanja o proizvodu, ljubazno vas molimo da kontaktirate direktno proizvođača kako biste dobili sve detaljne informacije.

Za najnovije informacije o ceni, dostupnim akcijama i tehničkim karakteristikama proizvoda koji se pominje u ovom dokumentu, molimo posetite našu stranicu klikom na sledeći link:

<https://tehnoteka.rs/p/energy-sistem-slusalice-style-1-snow-bele-akcija-cena/>