

Uputstvo za upotrebu

CANYON bluetooth zvučnik BSP-8 crni



Tehnoteka je online destinacija za upoređivanje cena i karakteristika bele tehnike, potrošačke elektronike i IT uređaja kod trgovinskih lanaca i internet prodavnica u Srbiji. Naša stranica vam omogućava da istražite najnovije informacije, detaljne karakteristike i konkurentne cene proizvoda.

Posetite nas i uživajte u ekskluzivnom iskustvu pametne kupovine klikom na link:

<https://tehnoteka.rs/p/canyon-bluetooth-zvucnik-bsp-8-crni-akcija-cena/>



Portable wireless speaker BSP-8
Quick Guide v 1.0

ENG

Quick guide Wireless speaker

Features

- Portable wireless speaker BSP-8
- RGB backlight
- BT version 5.2
- Working range: up to 10 m
- Playing time: up to 3 h
- Sources: BT, TF card, AUX, USB
- Power: 10W
- Transmit power per channel: <20mW
- Compatibility: Win/iOS/Android

Bluetooth:

- 1. Long press the power button

- 9 for 2-3s. The LED light will turn on briefly and then turn off.
- 2. Activate Bluetooth on your device and search for "Canyon BSP-8" then connect it and pair the device. The RGB backlight will be turned on.
- 3. Press Play/Pause button 3 to play/pause the music.
- 4. Briefly click Previous or Next buttons 2 or 4 to adjust volume down or up.
- 5. Hold the buttons to switch to the previous or next track.

- Making calls in BT mode:
1. Long press the button 3 to dial the nearest call.
Click the button 3 to answer a call, or a long press button 3 to reject. During a call, click the button 3 to hang up.
- TWS mode
1. Long press the power button 9 for 2-3s to turn on two same speakers within 1 meter from each other.
2. Double-click "MODE" button and speakers will be paired automatically.
3. Activate BT on your device and

- find "Canyon BSP-8", then connect it and pair the device.
4. Double-click "MODE" button to exit this mode.
- Playing music from USB:
1. Long press the power button 9 for 2-3s to turn on the speaker.
2. Insert USB stick into the slot. The speaker will start playing the music automatically.
3. Click the "MODE" button if the USB stick is already inserted, select the right mode by pressing the "MODE" button 5.
3. Press Play/Pause button 3 to play/pause the music.
4. Previous/Vol+ and Next/Vol+ buttons 2-4 as in bluetooth mode (see above).

TF card mode

- 1. Long press the power button 9 for 2-3s to turn on two same speakers within 1 meter from each other.
2. Double-click "MODE" button and speakers will be paired automatically.
3. Activate BT on your device and

- turn on the device.
4. Briefly click Previous or Next buttons 2 or 4 to adjust volume down or up.
- 5. Hold the buttons to switch to the previous or next track.

Charging:

- 1. Connect the power cable into the charging port 2, connect the other end to any charger with DC5V 500-1000mA output, the red charging indicator will remain on.
2. Charge time should be 3 hours. When fully charged, the indicator light will switch off.
- 2. Previous/Vol+ and Next/Vol+ buttons 2-4 as in bluetooth mode (see above).

AUX-IN:

- For other compatible device use the audio line cable to connect from the device's "Line Out" to the "Aux In" of the speaker.

Pairing:

- 1. Long press the power button 9 to change the 5 RGB backlight modes.
- 2. Insert USB stick into the slot. The speaker will start playing the music automatically.
3. Click the "MODE" button if the USB stick is already inserted, select the right mode by pressing the "MODE" button 5.
3. Press Play/Pause button 3 to play/pause the music.
4. Previous/Vol+ and Next/Vol+ buttons 2-4 as in bluetooth mode (see above).

WARNINGS

1) Using speakers at a high volume level for a long time can lead to temporary or permanent hearing loss.

2) The device housing shall not be removed. Any attempt to perform an unauthorized device repair is not recommended and will void the warranty.

WARRANTY

- The warranty period starts from the day of the product purchase from CANYON authorized SELLER. The date of purchase, is the date specified on your sales receipt or on the waybill. During the warranty period, repair or replacement of the device for the purchase shall be performed by the distributor of CANYON. If you have any questions about the service, the goods must be returned to the Seller at the place of purchase together with the proof of purchase (receipt or bill of lading), 2 years from the date of purchase by the consumer. The service life is 2 years. Additional information about the use and warranty is available at <http://canyon.eu/warranty-terms/>

- Date of manufacture: (see at the package). Made in China.
Manufacturer: ASBISc Enterprises PLC, lapetou, 1, Agios Athanasios, 4101, Limassol, Cyprus, +357 25 857000, asbis.com

dovesti do trougona ili tragicnog smrtonosnog slaha.

2. Kudate uređaju se u visokim odstojanju. Svako neuvlačeno servisiranje uređaja nije preporučljivo jer može ponistiti garanciju.

GARANCIJA

Garantni period počinje od dana kupovine Canyon produkte kod ovlaštenog prodavača. Datum kupovine je datum označenja na računu. U slučaju traženja informacija o garantiji, kontaktirajte prodavača ili ovlaštenog servisnog centra iz CAYON-a. Kada bi se ispunili uslovi garancije, prizovak mora biti vraken na pristupno mjesto odjde je kupljenu zajedno sa dokazom o kupovini (račun). Garancija traje 2 godine od datuma kupovine. Vrijek trajanja je 2 godine. Dodatne informacije o upotrebi i garanciji dostupne su na <http://canyon.eu/warranty-terms/>

Datum provozne (vidi na pakiranju). Zambla porijekla: Kina.
Proizvođač: Asbic Enterprises PLC, 43, Kolonakiou Street, Diamond Court 4101 Agios Athanasios Limassol - Cyprus
<http://canyon.eu>

BOS

Uputstvo.

Bezični zvučnici

Karakteristike

- Prijenosi bežični zvučnik BSP-8
- RGB pozadinski osvetljenje
- BT verzija 5.2
- Radni doseg: do 10 m
- Vrijeme reprodukcije: do 3 h
- Izvori: BT, TF kartica, AUX, USB
- Snaga: 10W
- Snaga prenosa po kanalu: <20mW
- Kompatibilnost: Win/iOS/Android

Brisanje:

- 1. Dug pritiskite dugme za napajanje s u trajanjem od 2-3 sekunde. LED svjetlo će postati plavo i briće se.

- 2. Aktivirajte Bluetooth na svom uređaju i potražite "Canyon BSP-8", potom ga povežite i upravite uredjaj.

- 3. Pritisnite dugme Play/Pause 3 da prepoznete/pauzirajte.

- 4. Dvaput kliknite na dugme za napajanje s u trajanjem od 2-3 sekunde. LED svjetlo će postati plavo i briće se.

Obavljanje poziva s BT modu:

- Dvaput kliknite na dugme 3 da biste pozvali najbliži poziv.

- Pritisnite dugme 3 da odgovorte na poziv ili dugi pritisnite dugme 3 da odobjete.

TWS mode:

- 1. Dug pritiskite dugme za napajanje s u trajanjem od 2 sekunde. Zatim uključite TWS funkciju.

- 2. Dvaput kliknite na dugme 3 da biste prepoznete TWS funkciju.

RGB pozadinsko osvetljenje:

- Kliknite na dugme 9 da pronadite 5 režima RGB pozadinskog osvetljenja.

AUX-IN:

- FZ2 druge kompatibilne uređaju upotrijebite ispručeni audio kabel sa sružnjicom na Lline Out uređaju na "Aux In" zvučnika.

BUL

Kratko rječnikovstvo

Bezični vисокоговоритељ

Xarakteristika

- Prijenosi bežični vissokogovoriteљ - Rgb pozadinski osvetljenje
- BT verzija 5.2
- Radni doseg: do 10 m
- Vrijeme reprodukcije: do 3 h
- Izvori: BT, TF kartica, AUX, USB
- Snaga: 10W
- Snaga prenosa po kanalu: <20mW
- Kompatibilnost: Win/iOS/Android

Brisanje:

- 1. Dug pritiskite dugme za napajanje s u trajanjem od 2-3 sekunde. LED svjetlo će postati plavo i briće se.

- 2. Aktivirajte Bluetooth na svom uređaju i potražite "Canyon BSP-8", potom ga povežite i upravite uredjaj.

- 3. Pritisnite dugme Play/Pause 3 da prepoznete/pauzirajte.

- 4. Dvaput kliknite na dugme za napajanje s u trajanjem od 2-3 sekunde. LED svjetlo će postati plavo i briće se.

Obavljanje poziva s BT modu:

- Dvaput kliknite na dugme 3 da biste pozvali najbliži poziv.

- Pritisnite dugme 3 da odgovorte na poziv ili dugi pritisnite dugme 3 da odobjete.

TWS mode:

- 1. Dug pritiskite dugme za napajanje s u trajanjem od 2 sekunde. Zatim uključite TWS funkciju.

- 2. Dvaput kliknite na dugme 3 da biste prepoznete TWS funkciju.

RGB pozadinsko osvetljenje:

- Kliknite na dugme 9 da pronadite 5 režima RGB pozadinskog osvetljenja.

AUX-IN:

- FZ2 druge kompatibilne uređaju upotrijebite ispručeni audio kabel sa sružnjicom na Lline Out uređaju na "Aux In" zvučnika.

CES

Rychlý průvodce

Bezdrátový reproduktor

Funkce

- Přenosný bezdrátový reproduktor
- RGB podsvětka
- BT verze 5.2
- Režim obrazovky: do 10 m
- Výkon: 10W
- Snášení: 100g
- Snášení pro využití: <20mW
- Snášení: 100g
- Kompatibilita: Win/iOS/Android

Bluetooth:

- 1. Aktivujte tlačítko na 9 sekund. LED světlo bude mít výraznou modulaci.

- 2. Aktivujte Bluetooth na svém uredjaju a potražite "Canyon BSP-8", pak ji připojte a spusťte.

- 3. Pritisněte tlačítko na 9 sekund. LED světlo bude mít výraznou modulaci.

- 4. Aktivujte tlačítko na 9 sekund. LED světlo bude mít výraznou modulaci.

Režim TWS

- 1. Aktivujte tlačítko na 9 sekund. LED světlo bude mít výraznou modulaci.

- 2. Pritisněte tlačítko na 9 sekund. LED světlo bude mít výraznou modulaci.

RGB podsvětlení

- Klikněte na tlačítko na 9 sekund. LED světlo bude mít výraznou modulaci.

- 2. Pritisněte tlačítko na 9 sekund. LED světlo bude mít výraznou modulaci.

AUX-IN:

- Připojte externí audio kabel s konektorem 3,5 mm na zadní stranu uredjaju.

DEU

Kurzanleitung

Drahtloser Lautsprecher

Eigenschaften

- Tragbarer, beziehungsweise
portabler Lautsprecher
- RGB-Hintergrundbeleuchtung
- BT Version 5.2
- Arbeitsbereich: bis zu 10 m
- Spieldauer: bis zu 3 Stunden
- Leistung: 10W
- Übertragungsreichweite: <20mW
- Kompatibilität: Win/iOS/Android

Bluetooth:

- 1. Drücken Sie die Einschalttaste für 9 lang für 2-3 Sekunden. Kontrollleuchte LED leuchtet blau.

- 2. Aktivieren Sie Bluetooth auf Ihrem Gerät und suchen Sie nach "Canyon BSP-8", um sie mit dem Gerät zu verbinden.

- 3. Drücken Sie die Tasten "Play/Pause" 3, um die Musik abzuhören.

- 4. Drücken Sie die Tasten "Play/Pause" 3, um die Musik abzuhören.

Reaktivieren der TWS-Funktion

- 1. Drücken Sie die Einschalttaste für 9 lang für 2-3 Sekunden. Kontrollleuchte LED leuchtet grün.

- 2. Drücken Sie die Tasten "Play/Pause" 3, um die Musik abzuhören.

RGB-Hintergrundbeleuchtung:

- Klicken Sie auf die Taste 9, um die RGB-Hintergrundbeleuchtung zu ändern.

- 2. Drücken Sie die Tasten "Play/Pause" 3, um die RGB-Hintergrundbeleuchtung zu ändern.

AUX-IN:

- Verbinden Sie den drahtlosen Lautsprecher mit einem anderen Gerät über den Anschluss "Aux In".

EST

Kiirjuhind

Juhitavneba kõlar

Ovaj dokument je originalno proizveden i objavljen od strane proizvođača, brenda Canyon, i preuzet je sa njihove zvanične stranice. S obzirom na ovu činjenicu, Tehnoteka ističe da ne preuzima odgovornost za tačnost, celovitost ili pouzdanost informacija, podataka, mišljenja, saveta ili izjava sadržanih u ovom dokumentu.

Napominjemo da Tehnoteka nema ovlašćenje da izvrši bilo kakve izmene ili dopune na ovom dokumentu, stoga nismo odgovorni za eventualne greške, propuste ili netačnosti koje se mogu naći unutar njega. Tehnoteka ne odgovara za štetu nanesenu korisnicima pri upotrebi netačnih podataka. Ukoliko imate dodatna pitanja o proizvodu, ljudazno vas molimo da kontaktirate direktno proizvođača kako biste dobili sve detaljne informacije.

Za najnovije informacije o ceni, dostupnim akcijama i tehničkim karakteristikama proizvoda koji se pominje u ovom dokumentu, molimo posetite našu stranicu klikom na sledeći link:

<https://tehnoteka.rs/p/canyon-bluetooth-zvucnik-bsp-8-crni-akcija-cena/>