

Uputstvo za upotrebu (kratko EN)

ZOTAC nVidia GeForce RTX 4080 Trinity OC 16GB GDDR6X
256-bit grafička kartica

ZOTAC



Tehnoteka je online destinacija za upoređivanje cena i karakteristika bele tehnike, potrošačke elektronike i IT uređaja kod trgovinskih lanaca i internet prodavnica u Srbiji. Naša stranica vam omogućava da istražite najnovije informacije, detaljne karakteristike i konkurentne cene proizvoda.

Posetite nas i uživajte u ekskluzivnom iskustvu pametne kupovine klikom na link:




<https://tehnoteka.rs/p/zotac-nvidia-geforce-rtx-4080-trinity-oc-16gb-gddr6x-256-bit-graficka-kartica-akcija-cena/>

GRAPHICS CARD INSTALLATION

01
Power Off the computer. Unplug the cable(s) connected to the system, and remove any existing discrete graphics card(s).

02
Remove the system case cover and locate the PCI Express x16 slot on the motherboard. Please refer to your motherboard specifications.

03
Remove the expansion slot cover(s) for the available slot(s) where the graphics card will be installed.






GRAPHICS CARD INSTALLATION

04/05
Insert the card firmly into the expansion slot. Secure the graphics card using the system case screw(s).

06
Connect any required PCI-e power cable(s) from the system power supply to the graphics card. Power requirements may vary by graphics card model.

07
Replace the system case cover and reconnect the system power cable.



GEFORCE DRIVER INSTALLATION

PLEASE MAKE SURE TO HAVE THE LATEST AVAILABLE DRIVERS INSTALLED FOR YOUR ZOTAC GAMING GEFORCE GRAPHICS CARD FOR OPTIMAL GAMING PERFORMANCE.

NOTE: The latest GeForce Drivers are available at GEFORCE.com. An Internet connection is required to proceed.



DRIVER DOWNLOAD

CONNECT A MONITOR

CONNECTING A DISPLAY TO THE GRAPHICS CARD

MORE YOU NEED TO KNOW



ZOTAC.COM






USEFUL LINKS

PRODUCT REGISTRATION
Register your new product on ZOTAC.COM to get FREE extended product warranty where applicable. Product registration must be successfully submitted within a limited time of new product purchase. Availability and window of time for product registration may vary by product and region.

FIRESTORM UTILITY
Our advanced fine-tuning software utilizes a simplified design to allow easy and immersive control of your ZOTAC and ZOTAC GAMING graphics cards. Monitor GPU performance, adjust the speed of clock, memory and fan, customize fan profile as well as SPECTRA RGB lighting, and do much more.

SUPPORT/CONTACT US
Need any help with your ZOTAC products? Please go to our Support page to find the answers, or simply contact us so we can provide the needed support.



SUPPORT CONTACT US






WARRANTY

EXTENDED WARRANTY
ZOTAC products come with a standard warranty period. In addition, customers will be entitled to extended product warranty through an online product registration process within a limited time of new product purchase where applicable. ZOTAC reserves the right to change the terms and conditions without advance notice.

NOTE!
All warranty conditions and terms are subject to change without prior notice. For current warranty details, please check our online policies at ZOTAC.COM

NOTE!
ZOTAC Technology Ltd. reserves the right to void the warranty if:
- The product is physically modified, unless otherwise stated.
- If user did not damage the product, including abuse, over-clocking, natural disaster, negligence, misuse, modifications (cooling included), power supply, damage due to the result of other damaged components, etc.
- Product was used for its intended purpose

Under no circumstances is ZOTAC Technology Ltd. held liable for any lost wages or revenues incurred due to defective or damaged products. ZOTAC Technology Ltd. does not provide any additional warranty for its products except as stated in the warranty terms, whether by implication or merchant implication.





快读安装指南

基本安装
1. 关闭计算机电源，断开连接主机电机的电源，并断开与显示器连接的电缆。并拆除任何现有的独立显卡。

02
移除系统机箱盖，并定位主板上的 PCI Express x16 插槽。请参考您的主板规格。

03
移除插槽盖，以便将显卡安装在可用插槽中。






GUIDE D'INSTALLATION RAPIDE

INSTALLATION DE LA CARTE GRAPHIQUE
1. Arrêter le système informatique et débrancher le câble d'alimentation principal. Débrancher également les câbles de connexion de votre écran.

02
Retirez le couvercle du boîtier de votre système informatique et localisez le slot PCI Express x16 sur la carte mère.

03
Retirez le couvercle du slot de la carte graphique pour permettre à la carte graphique d'être installée dans le slot.






快速安装指南

基本安装
1. 关闭计算机电源，断开连接主机电机的电源，并断开与显示器连接的电缆。并拆除任何现有的独立显卡。

02
移除系统机箱盖，并定位主板上的 PCI Express x16 插槽。请参考您的主板规格。

03
移除插槽盖，以便将显卡安装在可用插槽中。




QUÉBEC D'INSTALLATION RAPIDE

INSTALLATION DE LA CARTE GRAPHIQUE
1. Arrêter le système informatique et débrancher le câble d'alimentation principal. Débrancher également les câbles de connexion de votre écran.

02
Retirez le couvercle du boîtier de votre système informatique et localisez le slot PCI Express x16 sur la carte mère.

03
Retirez le couvercle du slot de la carte graphique pour permettre à la carte graphique d'être installée dans le slot.





快速安装指南

基本安装
1. 关闭计算机电源，断开连接主机电机的电源，并断开与显示器连接的电缆。并拆除任何现有的独立显卡。

02
移除系统机箱盖，并定位主板上的 PCI Express x16 插槽。请参考您的主板规格。

03
移除插槽盖，以便将显卡安装在可用插槽中。






快读安装指南

基本安装
1. 关闭计算机电源，断开连接主机电机的电源，并断开与显示器连接的电缆。并拆除任何现有的独立显卡。

02
移除系统机箱盖，并定位主板上的 PCI Express x16 插槽。请参考您的主板规格。

03
移除插槽盖，以便将显卡安装在可用插槽中。



ZOTAC.COM



FIRESTORM



SUPPORT CONTACT US



NOTE!



NOTE!



NOTE!



NOTE!



NOTE!



NOTE!



ZOTAC.COM



FIRESTORM



SUPPORT CONTACT US



NOTE!



NOTE!



NOTE!



NOTE!



NOTE!



NOTE!

ZOTAC.COM

FIRESTORM

SUPPORT CONTACT US

NOTE!

NOTE!

NOTE!

NOTE!

NOTE!

NOTE!

ZOTAC.COM

FIRESTORM

SUPPORT CONTACT US

NOTE!

NOTE!

NOTE!

NOTE!

NOTE!

NOTE!

ZOTAC.COM

FIRESTORM

SUPPORT CONTACT US

NOTE!

NOTE!

NOTE!

NOTE!

NOTE!

NOTE!

ZOTAC.COM

FIRESTORM

SUPPORT CONTACT US

NOTE!

NOTE!

NOTE!

NOTE!

NOTE!

NOTE!

ZOTAC.COM

FIRESTORM

SUPPORT CONTACT US

NOTE!

NOTE!

NOTE!

NOTE!

NOTE!

NOTE!

ZOTAC.COM

FIRESTORM

SUPPORT CONTACT US

NOTE!

NOTE!

NOTE!

NOTE!

NOTE!

NOTE!

ZOTAC.COM

FIRESTORM

SUPPORT CONTACT US

NOTE!

NOTE!

NOTE!

NOTE!

NOTE!

NOTE!

ZOTAC.COM

FIRESTORM

SUPPORT CONTACT US

NOTE!

NOTE!

NOTE!

NOTE!

NOTE!

NOTE!

ZOTAC.COM

FIRESTORM

Ovaj dokument je originalno proizveden i objavljen od strane proizvođača, brenda ZOTAC, i preuzet je sa njihove zvanične stranice. S obzirom na ovu činjenicu, Tehnoteka ističe da ne preuzima odgovornost za tačnost, celovitost ili pouzdanost informacija, podataka, mišljenja, saveta ili izjava sadržanih u ovom dokumentu.

Napominjemo da Tehnoteka nema ovlašćenje da izvrši bilo kakve izmene ili dopune na ovom dokumentu, stoga nismo odgovorni za eventualne greške, propuste ili netačnosti koje se mogu naći unutar njega. Tehnoteka ne odgovara za štetu nanесenu korisnicima pri upotrebi netačnih podataka. Ukoliko imate dodatna pitanja o proizvodu, ljubazno vas molimo da kontaktirate direktno proizvođača kako biste dobili sve detaljne informacije.

Za najnovije informacije o ceni, dostupnim akcijama i tehničkim karakteristikama proizvoda koji se pominje u ovom dokumentu, molimo posetite našu stranicu klikom na sledeći link:

<https://tehnoteka.rs/p/zotac-nvidia-geforce-rtx-4080-trinity-oc-16gb-gddr6x-256-bit-graficka-kartica-akcija-cena/>