

Uputstvo za upotrebu (EN)

ENERGY SISTEM slušalice Style 2+ Raspberry

ENERGY  SISTEM



Tehnoteka je online destinacija za upoređivanje cena i karakteristika bele tehnike, potrošačke elektronike i IT uređaja kod trgovinskih lanaca i internet prodavnica u Srbiji. Naša stranica vam omogućava da istražite najnovije informacije, detaljne karakteristike i konkurentne cene proizvoda.

Posetite nas i uživajte u ekskluzivnom iskustvu pametne kupovine klikom na link:

<https://tehnoteka.rs/p/energy-sistem-slusalice-style-2-raspberry-akcija-cena/>

ENGLISH

Introduction 2

Care and maintenance 2

General overview 2

Call control* 3

 Answer a call 3

 End a call 3

 Reject a call 3

Safety 3

Warranty 3

 Trademarks 3

Declaration of conformity 3

Introduction


- Thank you for your trust in our company and for buying your new Earphones. We hope you enjoy them.
- We recommend you to read this quick guide to familiarize yourself with your earphones before using them.

Care and maintenance

- Do not expose your earphones to impacts, dust, humidity or high temperatures.
- Do not use neither corrosive nor abrasive cleaning products.
- Do not disassemble the device. All modifications are to be carried out exclusively by qualified staff of Energy Sistem Technology, S.A.
- Avoid pulling and twisting cables to extend the life of your earphones.

General overview

- Plug the 3.5 mm JACK CONNECTOR (2) of your earphones into the earphones input of the device that you are using to play your music.
- Press the MICROPHONE (3) button to control the playback of your music. Press this button once to pause/resume playback. Press it twice to move to the next track. Press it three times to move to the previous track.*



1. Driver
2. 3.5 mm jack connector
3. Microphone

Call control*

You will be able to control your calls from your earphones if you plug them into your mobile phone.

Answer a call

Press the MICROPHONE (3) button once to answer a call.

End a call

Press and hold the MICROPHONE (3) button for approximately 2 seconds to end a call.

Reject a call

Press and hold the MICROPHONE (3) button for approximately 2 seconds to reject a call.

**Controls may vary depending on the settings of the device that you are using to play your music.*

Safety

- Before using the earphones, turn the volume down and turn it up slowly until desired music level is achieved.
- Avoid noisy environments that force you to turn up the volume really high when using your earphones.
- Listening to loud music through earphones over a long period of time may cause your ears to get used to high volume levels, resulting in irreversible hearing loss.
- Adjust the volume of your earphones to be able to hear important external sounds.

Warranty

You can check the warranty terms here:

<https://www.energysistem.com/terms-warranty>

Trademarks

All company, brand and product names are trademarks or registered trademarks of their respective companies.

Specifications are subject to change without notice.

© 2018 by Energy Sistem Technology, S.A. All rights reserved.

Declaration of conformity

Issuer's name: Energy Sistem Technology, S.A.

Address: C/ Calpe, 1 - 03509 Finestrat, Alicante (Spain)

Tel: +34 966 830 324

CIF: A53107488

We declare under our own exclusive responsibility that the product:

Description: Earphones

Brand: Energy Sistem

Manufacturer: Energy Sistem Technology, S.A.

Manufacturing country: China

in conformity with the essential norms and standards of the Directive EMC 2014/30/EU of the European Parliament and of the Council of 26th February 2014.

Finestrat, 1st February 2018



Miguel Ángel Aragüez García
Innovation and Technology Director



Ovaj dokument je originalno proizveden i objavljen od strane proizvođača, brenda Energy Sistem, i preuzet je sa njihove zvanične stranice. S obzirom na ovu činjenicu, Tehnoteka ističe da ne preuzima odgovornost za tačnost, celovitost ili pouzdanost informacija, podataka, mišljenja, saveta ili izjava sadržanih u ovom dokumentu.

Napominjemo da Tehnoteka nema ovlašćenje da izvrši bilo kakve izmene ili dopune na ovom dokumentu, stoga nismo odgovorni za eventualne greške, propuste ili netačnosti koje se mogu naći unutar njega. Tehnoteka ne odgovara za štetu nanесenu korisnicima pri upotrebi netačnih podataka. Ukoliko imate dodatna pitanja o proizvodu, ljubazno vas molimo da kontaktirate direktno proizvođača kako biste dobili sve detaljne informacije.

Za najnovije informacije o ceni, dostupnim akcijama i tehničkim karakteristikama proizvoda koji se pominje u ovom dokumentu, molimo posetite našu stranicu klikom na sledeći link:

<https://tehnoteka.rs/p/energy-sistem-slusalice-style-2-raspberry-akcija-cena/>