

Uputstvo za upotrebu (EN)

A4 TECH bežična numerička tastatura Fstyler FGK21




Tehnoteka je online destinacija za upoređivanje cena i karakteristika bele tehnike, potrošačke elektronike i IT uređaja kod trgovinskih lanaca i internet prodavnica u Srbiji. Naša stranica vam omogućava da istražite najnovije informacije, detaljne karakteristike i konkurentne cene proizvoda.

Posetite nas i uživajte u ekskluzivnom iskustvu pametne kupovine klikom na link:

<https://tehnoteka.rs/p/a4-tech-bezicna-numericka-tastatura-fstyler-fgk21-akcija-cena/>

**QUICK
START
GUIDE**



FSTYLER
COLLECTION

WHAT'S IN THE BOX



2.4G Numeric Keypad



Nano USB Receiver



USB Type-C Adaptor



USB Type-C Charging Cable




User Manual

KNOW YOUR NUMERIC KEYPAD


Dual Modes Num Lock

- 1 Synchronous (Default)
- 2 Asynchronous (Press NumLock Key for 3s)




Backspace

CONNECTING 2.4G DEVICE



1

1 Plug the receiver into the computer USB port.



2 2-in-One

2 Use the Type-C adaptor to connect the receiver with the computer's Type-C port.




2

Turn the numeric keypad's power switch to on.

CHARGING & INDICATOR




- SOLID RED: CHARGING
- NO LIGHT: FULLY CHARGED



USB-A

USB-C



2H Charing Time


LOW BATTERY INDICATOR



Indicator

Flashing Red light indicates when the battery is below 25%.

TYPE-C RECHARGEABLE



Built-in Lithium Battery

TECH SPEC



Connection: 2.4G Hz	Keycap: Low-Profile
Operation Range: 10~15 m	Keys No.: 18
Report Rate: 125 Hz	Character: Laser Engraving
Charging Cable: 60 cm	Size: 87 x 124 x 24 mm
System: Windows 7/8/8.1/10/11	Weight: 88 g (w/ battery)

WARNING STATEMENT



The following actions may/will cause damages to the product.

1. To disassemble, bump, crush, or throwing into fire, you may cause irrefutable damages in event of the lithium battery leakage.
2. Do not expose under the strong sunlight.
3. Please obey all local laws when discarding the batteries, if possible please recycle it. Do not dispose it as household garbage, it may cause a fire or an explosion.
4. Please try to avoid charging in the environment below 0°C.
5. Do not remove or replace the battery.
6. Forbidden to use 6V to 24V charger, otherwise the product will be burned. Recommended to use a 5V charger for charging.



www.a4tech.com



Scan for E-Manual

Ovaj dokument je originalno proizveden i objavljen od strane proizvođača, brenda A4 Tech, i preuzet je sa njihove zvanične stranice. S obzirom na ovu činjenicu, Tehnoteka ističe da ne preuzima odgovornost za tačnost, celovitost ili pouzdanost informacija, podataka, mišljenja, saveta ili izjava sadržanih u ovom dokumentu.

Napominjemo da Tehnoteka nema ovlašćenje da izvrši bilo kakve izmene ili dopune na ovom dokumentu, stoga nismo odgovorni za eventualne greške, propuste ili netačnosti koje se mogu naći unutar njega. Tehnoteka ne odgovara za štetu nanесenu korisnicima pri upotrebi netačnih podataka. Ukoliko imate dodatna pitanja o proizvodu, ljubazno vas molimo da kontaktirate direktno proizvođača kako biste dobili sve detaljne informacije.

Za najnovije informacije o ceni, dostupnim akcijama i tehničkim karakteristikama proizvoda koji se pominje u ovom dokumentu, molimo posetite našu stranicu klikom na sledeći link:

<https://tehnoteka.rs/p/a4-tech-bezicna-numericna-tastatura-fstyler-fgk21-akcija-cena/>