

Uputstvo za upotrebu

S BOX slušalice EB-TWS115 roze



Tehnoteka je online destinacija za upoređivanje cena i karakteristika bele tehnike, potrošačke elektronike i IT uređaja kod trgovinskih lanaca i internet prodavnica u Srbiji. Naša stranica vam omogućava da istražite najnovije informacije, detaljne karakteristike i konkurentne cene proizvoda.

Posetite nas i uživajte u ekskluzivnom iskustvu pametne kupovine klikom na link:

<https://tehnoteka.rs/p/s-box-slusalice-eb-tws115-roze-akcija-cena/>

WARNING

1.Please do not overuse this earphone or put it under heavy pressure, keep away from wet and heat.

2.Keep away from WIFI,router or other high frequency transmitting equipment to prevent interruption of signal receiving.

3.Please use this earphone under its working range(10-15m),and the effect would be better if there is no obstacle between the connected devices.

4.Charging voltage current(5V 0.6-0.8A).Do not use other high voltage or high current chargers for charging.

SPECIFICATIONS

Bluetooth version:	V5.0+EDR(both sides),ultra low consumption
Bluetooth Mode:	A2DP1.3/HFP1.6/HSP1.2/AVRCP1.6/D11.3
Bluetooth Frequency:	2.4HZ
Battery capacity:	Built-in 35 mAh polymer lithium battery Charging dock: 200mAh
Standby time:	Both ears can stand for 50 hours
Talk/Play time:	Headphone playback time: 4-5 hours Headphone tale time approx: 5 hours

Headphone Use Steps And Special Instructions

1. Put the headset into the charging box to enter the charging mode, and the headset will automatically shut down.

2. Open the Bluetooth settings ofthe phone, take out earphones, and when the two earphones are paired by themselves (one is flashing, the other is not flashing), the phone will search the corresponding local model TWS-115 and click it to Connect Bluetooth.

3. If the headset is not connected to the Bluetooth device for 5 minutes, it will automatically shut down.

4. The number flashes when the charging box is charged, and it is always on when it is 100% full.

5.Turn the phone off and then turn it on again, the headset will automatically connect to it.

Third Generation Side Touch Menu

L/R press once: pause/play
L press 2 times: previous song
R press 2 times: next song
L press 3 times: Volume reduction
press 3 times: Volume up
Long press L/R for 2s: call the voice assistant

incoming call
L/R press 1 time: answer/hang up
Long press L/R for 2s: reject the call

UPOZORENJE

1. Molimo Vas da izbjegavate dugotrajno korištenje slušalice te da ih ne stavljate pod veliki pritisak i držite ih podalje od vage i topline.

2. Držite ih podalje od WiFi rutera ili drugih uređaja koji odašilju visoke frekvencije da bih izbjegli prekidanje signala.

3. Molimo Vas koristite ove slušalice u radnom dometu (10-15m), i signal će biti bolji ako nema prepreka između povezanih uređaja.

4. Jakost struje punjenja (5V 0.6-0.8A) Ne koristite druge punjače visoke voltaže ili visoko strujne punjače za punjenje.

KARAKTERISTIKE

Bluetooth verzija:	V5.0+EDR (obje strane), Ultra niska potrošnja
Bluetooth način rada:	A2DP1.3/HFP1.6/HSP1.2/AVRCP1.6/D11.3
Bluetooth frekvencija:	2.4 Hz
Kapacitet baterije:	Ugrađena 35 mAh lithium polymer baterija Kutijica za punjenje: 200 mAh
Vrijeme na čekanju:	Objek slušalice mogu biti na čekanju do 50 sati
Vrijeme razgovora/reprodukcije:	Vrijeme reprodukcije slušalice: 4-5 sati Vrijeme razgovora cca: 5 sati

Redoslijed korištenja slušalice i specijalne upute

1. Stavite slušalice u kutijicu za punjenje da bi ušli u mod za punjenje, i slušalice će se automatski ugasiti.

2. Otvorite Bluetooth opcije na Vašem mobilnom uređaju, izvadite slušalice, i kada se slušalice same povežu (jedna će treperiti a druga neće treperiti), mobilni uređaj će tražiti odgovarajući lokalni model TWS-115, kliknite na njega da bi ste se spojili sa Bluetooth-om.

3. Ako slušalice nisu povezane sa Bluetooth-om u sljedećih 5 minuta, automatski će se ugasiti.

4. Brojevi će treperiti kada je kutijica za punjenje puna, i stalno je upaljena kada je na 100% napunjenosti.

5. Ako ugasite pa upalite mobilni uređaj, slušalice će se automatski povezati.

Treća generacija bočnog dodirnog menu-a

Lijevu/Desnu slušalicu dodirnite jednom: pauza/početak
dvostruki dodir na Lijevu slušalicu: prethodna pjesma
dvostruki dodir na Desnu slušalicu: sljedeća pjesma
trostruki dodir na Lijevu slušalicu: smanjivanje glasnoće
trostruki dodir na Desnu slušalicu: pojačavanje glasnoće
Dugi dodir (2 sekunde) na Lijevu/Desnu slušalicu: pozivanje glasovnog asistenta

Dolazeći poziv
Dodirnite Lijevu/Desnu slušalicu jednom : javljanje/prekidanje
Dugi dodir (2 sekunde) na Lijevu/Desnu slušalicu: odbijanje poziva

Ovaj dokument je originalno proizveden i objavljen od strane proizvođača, brenda S BOX, i preuzet je sa njihove zvanične stranice. S obzirom na ovu činjenicu, Tehnoteka ističe da ne preuzima odgovornost za tačnost, celovitost ili pouzdanost informacija, podataka, mišljenja, saveta ili izjava sadržanih u ovom dokumentu.

Napominjemo da Tehnoteka nema ovlašćenje da izvrši bilo kakve izmene ili dopune na ovom dokumentu, stoga nismo odgovorni za eventualne greške, propuste ili netačnosti koje se mogu naći unutar njega. Tehnoteka ne odgovara za štetu nanесenu korisnicima pri upotrebi netačnih podataka. Ukoliko imate dodatna pitanja o proizvodu, ljubazno vas molimo da kontaktirate direktno proizvođača kako biste dobili sve detaljne informacije.

Za najnovije informacije o ceni, dostupnim akcijama i tehničkim karakteristikama proizvoda koji se pominje u ovom dokumentu, molimo posetite našu stranicu klikom na sledeći link:

<https://tehnoteka.rs/p/s-box-slusalice-eb-tws115-roze-akcija-cena/>