

## Uputstvo za upotrebu (EN)

COOLER MASTER kućište Cosmos C700M MCC-C700M-MG5N-S00



Tehnoteka je online destinacija za upoređivanje cena i karakteristika bele tehnike, potrošačke elektronike i IT uređaja kod trgovinskih lanaca i internet prodavnica u Srbiji. Naša stranica vam omogućava da istražite najnovije informacije, detaljne karakteristike i konkurentne cene proizvoda.

Posetite nas i uživajte u ekskluzivnom iskustvu pametne kupovine klikom na link:

<https://tehnoteka.rs/p/cooler-master-kuciste-cosmos-c700m-mcc-c700m-mg5n-s00-akcija-cena/>



**Make It Yours.**

# COSMOS C700M

User manual / English

التثبيت دليل / Arabic

Инструкция за експлоатация / Български

安装说明 / 简体中文

安裝說明 / 繁體中文

Uživatelská příručka / Čeština

Handuch / Deutsch

Εγχειρίδιο χρήσης / Ελληνικά

Manual de Usuario / Español

Manuel de l'utilisateur / Français

فارسی / راهنمای کاربری

Felhasználói kézikönyv / Magyar

Manuale d'uso / Italiano

ユーザーズマニュアル / 日本語

Handleiding / Nederlands

설치 안내 / Korean

Instrukcja Użytkownika / Polski

Manual do Usuário / Português

Руководство пользователя / русский

Uputstvo za korišćenje / Srpski

Kullanım Kılavuzu / Türkçe

Panduan Pengguna / Indonesia


















## CONTENTS


<b>Package Content</b>	<b>2</b>
<b>Front I/O &amp; Buttons</b>	<b>3</b>
<b>Compatibility</b>	<b>3</b>
<b>Installation Guide</b>	
<b>1</b> How to remove side panels	<b>4</b>
<b>2</b> How to install power supply	<b>4</b>
<b>3</b> How to install motherboard	<b>6</b>
<b>4</b> How to remove/install GFX bracket & SSD bracket	<b>7</b>
<b>5</b> How to install add-on cards	<b>8</b>
<b>6</b> How to install 5.25" devices	<b>10</b>
<b>7</b> How to install 3.5" devices	<b>13</b>
<b>8</b> How to install 2.5" devices	<b>15</b>
<b>9</b> How to install case fans and radiators	<b>17</b>
<b>10</b> How to install 420mm radiator	<b>18</b>
<b>11</b> How to install radiator in the rear	<b>21</b>
<b>12</b> Cable Management	<b>21</b>
<b>13</b> Completing installation	<b>22</b>
<b>Fan &amp; A-RGB controller operation</b>	<b>23</b>
<b>Control Board Layout</b>	<b>24</b>
<b>I/O connectors</b>	<b>24</b>
<b>Inverse layout adjustment</b>	<b>25</b>
<b>Chimney effect layout adjustment</b>	<b>30</b>

<b>Net Weight</b>		23.4kg / 51.6lb
<b>Available Color</b>		Grey, Silver & Black
<b>Materials</b>		Outlook: Aluminum, Plastic, Steel Body: Steel Side panel: Tempered Glass, Steel
<b>Dimensions (LxWxH)</b>		650 x 306 x 651mm / 25.6 x 12.0 x 25.6inch
<b>Motherboard Support</b>		Mini-ITX, Micro-ATX, ATX, E-ATX (support upto 12" x 10.7")
<b>Expansion Slots</b>		8
<b>Drive Bays</b>	5.25"	1
	2.5"/3.5"	4 + 1 (in the accessory box)
	2.5" SSD	4
<b>I/O Port</b>		USB 3.1 Type-C x 1 USB 3.0 Type-A x 4 3.5mm Headset Jack (Audio+Mic) x 1 3.5mm Mic Jack x 1 Fan Speed & A-RGB Control Buttons
<b>Pre-installed Fan(s)</b>	Front	140mm PWM Fan x 3 (Speed: 1200RPM / Connector: 4Pin PWM)
	Rear	140mm PWM Fan x 1 (Speed: 1200RPM / Connector: 4Pin PWM)
<b>Fan Support</b>	Top	120/140mm fan x 3
	Front	120/140mm fan x 3
	Rear	120/140mm fan x 1
	Bottom	120/140mm fan x 2
	<b>Liquid Cooling Support</b>	
<b>Clearances</b>	CPU Cooler	198mm
	GPU	490mm (without 3.5" HDD Bracket) 320mm (with 3.5" HDD Bracket)
<b>Power Supply Support</b>		Bottom Mount, ATX PS2


**Package Content / Lieferumfang / Contenido de la confección / Contenu de l'emballage / Contenuto della confezione / Zawartość opakowania / Содержание комплекта / Съдържание / baleni obshajne / Περιεχόμενα συσκευασίας / A csomag tartalma / Verpakkinginhoud / Conteúdo da embalagem / Sadržajpakovanja / Paket İçeriği / 包装内含物品明細 / 包装内含物品清單 / パッケージ内容 / Isi Paket / 구성품 내용 / فهرست محتويات / محتوی الطرذ**

	Figure	Name	Q'ty	Used for
1		2-Bay ODD or Function Panel bracket	2	2-Bay 5.25" optical drive or function Panel
2		#6-32*6mm screw	17	2-Bay 5.25" optical drive or function panel bracket, PSU, motherboard
3		M3*5mm screw	8	5.25" optical drive
4		HDD screw	20	HDD cage
5		SSD screw	12	Mounting SSD on M.port cover
6		Stand-off	3	Motherboard tray
7		Stand-off socket	1	Motherboard stand-off installation
8		Cable Tie	10	Cable management
9		φ5*10mm screw	8	Installing fans
10		Cleaning Cloth	1	Cleaning glass
11		M3*4mm screw	20	SSD / mounting in SSD pockets
12		#6-32*6mm screw	2	Tap thread on frame holes
13		HDD SSD combo bracket	1	Install 3.5" devices
14		A-RGB splitter + Sata connector	1	Adding more A-RGB lighting Requires additional power source from SATA
15		Riser Cable	1	Connecting graphics card when using the rotateable graphics card holder

<b>EN</b> Front I/O & Buttons	<b>HU</b> Előlap I/O & kapcsolók
<b>AR</b> المنافذ الأمامية والأزرار	<b>ID</b> Tombol dan I/O depan
<b>BG</b> Преден панел и бутони	<b>IT</b> Pulsanti e I/O frontali
<b>CHS</b> 前面板接口及按键说明	<b>JP</b> フロント I/O パネル
<b>CHT</b> 前面板接口及按键说明	<b>KR</b> 전면 I/O & 버튼
<b>CS</b> Vstupy/Výstupy a další tlačítka na předním panelu	<b>NL</b> Bedieningspaneel
<b>DE</b> Front I/O & Tasten	<b>PL</b> Przedni panel I/O & Przyciski
<b>EL</b> Εμπρός I/O & διακόπτες	<b>PT</b> Botões e frontal I/O
<b>ES</b> Frontal I/O & Botones	<b>RU</b> Фронтальные кнопки и панель ввода/вывода
<b>FA</b> دکمه‌ها و درگاه‌های پهن جلو	<b>SR</b> Front I/O & Tasteri
<b>FR</b> Boutons sur le panneau E/S de façade	<b>TR</b> Ön I/O & Düğmeler




<b>EN</b> Compatibility	<b>HU</b> kompatibilitás
<b>AR</b> التوافق	<b>ID</b> Kompatibilitas
<b>BG</b> съвместимост	<b>IT</b> Compatibilità
<b>CHS</b> 相容性	<b>JP</b> パーツ互換性
<b>CHT</b> 兼容性	<b>KR</b> 호환성
<b>CS</b> kompatibilita	<b>NL</b> Compatibiliteit
<b>DE</b> Kompatibilität	<b>PL</b> Zgodność
<b>EL</b> Συμβατότητα	<b>PT</b> Compatibilidade
<b>ES</b> Compatibilidad	<b>RU</b> Совместимость
<b>FA</b> سازگاری	<b>SR</b> kompatibilnost
<b>FR</b> Compatibilité	<b>TR</b> Uyumluluk



**198 mm**

Maximum height for CPU cooler





**490 mm**

Maximum length for Graphics card

## Installation Guide / Installationsanleitung / Guía para la instalación / Guide d'installation / Guida per l'installazione / Instrukcja instalacji / Руководство пользователя / Ръководство за инсталация / Instalační příručka / Οδηγός εγκατάστασης / Telepítési útmutató / / Guia de instalação / Uputstvo za instalaciju / Kurulum Kılavuzu / 組裝說明 / 組裝說明 / 製品の使い方 / Panduan Instalasi / 설치 안내 / راهنمای نصب / دليل التثبيت

### 1


- |            |                                     |           |                                     |
|------------|-------------------------------------|-----------|-------------------------------------|
| <b>EN</b>  | How to remove side panels           | <b>HU</b> | Oldalsó panel eltávolítása          |
| <b>AR</b>  | كيفية إزالة اللوح الجانبى           | <b>ID</b> | Cara melepaskan panel samping       |
| <b>BG</b>  | Как се отстранява страничният панел | <b>IT</b> | Come rimuovere il pannello laterale |
| <b>CHS</b> | 移除側板                                | <b>JP</b> | サイドパネルの取り外し方法                       |
| <b>CHT</b> | 移除側板                                | <b>KR</b> | 사이드 패널 제거 방법                        |
| <b>CS</b>  | Jak odstranit boční kryt            | <b>NL</b> | Verwijderen van het zijpaneel       |
| <b>DE</b>  | So entfernen Sie das Seitenpanel    | <b>PL</b> | Jak zdjąć pokrywę boczną            |
| <b>EL</b>  | Πως να αφαιρέσετε το πλευρό κάλυμα  | <b>PT</b> | Como remover o painel lateral       |
| <b>ES</b>  | Como extraer el panel lateral       | <b>RU</b> | Как снять боковую панель            |
| <b>FA</b>  | نحوه باز کردن پیل کناری             | <b>SR</b> | Kako da uklonite bočnu stranicu     |
| <b>FR</b>  | Comment retirer le panneau latéral  | <b>TR</b> | Yan paneli kaldırma                 |








### 2

- |            |   |           |                                      |
|------------|---|-----------|--------------------------------------|
| <b>EN</b>  | How to install power supply             | <b>HU</b> | Tápegység beszerelése                |
| <b>AR</b>  | كيفية تثبيت موثر الطاقة                 | <b>ID</b> | Cara memasang power supply           |
| <b>BG</b>  | Как се поставя захранващият блок        | <b>IT</b> | Come installare l'alimentatore       |
| <b>CHS</b> | 安裝電源                                    | <b>JP</b> | 電源ユニットの取り付け方法                        |
| <b>CHT</b> | 安裝電源                                    | <b>KR</b> | 파워 서플라이 설치 방법                        |
| <b>CS</b>  | Jak zapojit zdroj                       | <b>NL</b> | Installeren van de voeding           |
| <b>DE</b>  | So installieren Sie das Netzteil        | <b>PL</b> | Jak podłączyć zasilanie              |
| <b>EL</b>  | Πως να εγκαταστήσετε το τροφοδοτικό     | <b>PT</b> | Como instalar a fonte de alimentação |
| <b>ES</b>  | Como instalar la fuente de alimentación | <b>RU</b> | Как установить блок питания          |
| <b>FA</b>  | نحوه نصب منبع تغذیه                     | <b>SR</b> | Kako da instalirate napajanje        |
| <b>FR</b>  | Comment installer l'alimentation        | <b>TR</b> | Güç kaynağını kurma                  |


## A Install regular PSU



## B Install longer PSU







**3**

**EN** How to install motherboard

**AR** كيفية تثبيت اللوحة الأم

**BG** Как се инсталира дънната платка

**CHS** 安裝主板

**CHT** 安裝主機板

**CS** Jak nainstalovat motherboard

**DE** So installieren Sie das Motherboard

**EL** Πως να εγκαταστήσετε τη μητρική κάρτα

**ES** Como instalar la placa base

**FA** نحوه نصب مادربرد

**FR** Comment installer la carte mère

**HU** Alaplap beszerelése

**ID** Cara memasang motherboard

**IT** Come installare la motherboard

**JP** マザーボードの取り付け方法

**KR** 마더보드 설치 방법

**NL** Installeren van het moederbord

**PL** Jak zamontować płytę główną


**PT** Como instalar a placa-mãe

**RU** Как установить материнскую плату


**SR** Kako da instalirate matičnu ploču




**TR** Anakartı kurma

## **A** Internal installation (for ATX)



## **B** External installation (for ATX)








**For other motherboard sizes please refer to motherboard manual. You may need to remove 1 or more the pre-installed stand-offs for proper installation.**

## 4

- |  |  |
|--|--|
| <b>[EN]</b> How to remove/install GFX bracket & SSD bracket                                    | <b>[HU]</b> Hogyan telepítsük/távolítsuk el a GFX és SSD keretet         |
| <b>[AR]</b> قرص و الرسوميات بطاقة حامل فك و تركيب طريفة SSD                                    | <b>[ID]</b> Cara Instalasi / Melepas Braket GFX & Braket SSD             |
| <b>[BG]</b> Как се монтира/премахваат скобите за графична карта и SSD.                         | <b>[IT]</b> Come installare / rimuovere la staffa GFX e la staffa SSD    |
| <b>[CHS]</b> 安裝/拆卸显卡支架和SSD支架   | <b>[JP]</b> グラフィックスカードブラケットおよびSSDブラケットの取付け/取外しの仕方                        |
| <b>[CHT]</b> 安裝/拆卸顯示卡支架和SSD支架  | <b>[KR]</b> GFX 브라켓 및 SSD 브라켓 설치 / 제거 방법                                 |
| <b>[CS]</b> Jak nainstalovat / odebrat držák GFX a držák SSD                                   | <b>[NL]</b> Installeren/verwijderen van videokaart bracket & SSD bracket |
| <b>[DE]</b> Ein-/Ausbau von Grafikkarten-Halterung und SSD-Halterung                           | <b>[PL]</b> Jak zamontować/usunąć ramkę GFX i SSD                        |
| <b>[EL]</b> Πώς να εγκαταστήσετε / αφαιρέσετε το GFX bracket & SSD bracket                     | <b>[PT]</b> Como instalar/remover os brackets GFX e SSD                  |
| <b>[ES]</b> Cómo instalar / extraer el soporte GFX y el soporte SSD                            | <b>[RU]</b> Как установить/удалить кронштейн GFX и кронштейн SSD.        |
| <b>[FA]</b> SSD و کی-گراف کارت برکت یساز جدا و نصب یچگونگ                                      | <b>[SR]</b> Kako instalirati/ukloniti GFX nosač & SSD nosač              |
| <b>[FR]</b> Comment installer / retirer le support pour carte graphique et le support pour SSD | <b>[TR]</b> GFX ve SSD Desteği Nasıl Takılır/Çıkartılır                  |



## 5

**EN** How to install add-on cards

**AR** كيفية تثبيت بطاقات مضافة

**BG** Как се инсталират допълнителните платини

**CHS** 安装显卡

**CHT** 安裝顯示卡

**CS** Jak nainstalovat přídavné karty

**DE** So installieren Sie Erweiterungskarten

**EL** Πως να εγκαταστήσετε πρόσθετες κάρτες

**ES** Como instalar tarjetas adicionales

**FA** نحوه نصب کارت‌ها

**FR** Comment installer les cartes supplémentaires

**HU** Add-on kártyák beszerelése

**ID** Cara memasang perangkat kartu tambahan

**IT** Come installare le schede aggiuntive

**JP** 拡張カードの取り付け方法

**KR** 애드 온 카드 설치 방법

**NL** Installeren van de extra kaarten

**PL** Jak podłączyć karty rozszerzeń

**PT** Como instalar as placas adicionais

**RU** Как установить карты расширения







**SR** Kako da instalirate dodatne kartice





**TR** Eklenli kartlarını kurma

**A** Regular position

**B** Install on midplate

**C** Install on M.Port











## 6

- [EN] How to install 5.25" devices
- [AR] كيفية تثبيت الأجهزة مقاس 5.25 بوصة
- [BG] Как се инсталират 5,25" устройствата
- [CHS] 安裝5.25"裝置
- [CHT] 安裝5.25"裝置
- [CS] Jak nainstalovat zařízení 5.25"
- [DE] So installieren Sie 5.25" Zoll Geräte
- [EL] Πως να εγκαταστήσετε τις συσκευές 5,25"
- [ES] Como instalar los dispositivos de 5,25"
- [FA] نحوه نصب درایوهای 5.25 اینچ
- [FR] Comment installer les périphériques 5,25 pouces


- [HU] 5,25" eszközök beszerelése
- [ID] Cara memasang perangkat 5.25
- [IT] Come installare le unità da 5.25"
- [JP] 5.25"インチデバイス（光学ドライブなど）の取り付け方法
- [KR] 5.25인치 장치 설치 방법
- [NL] Installeren van de 5.25" apparaten
- [PL] Jak zamontować urządzenia 5.25"
- [PT] Como instalar os dispositivos de 5,25"
- [RU] Как установить 5,25" устройства
- [SR] Kako da instalirate 5,25" uređaje
- [TR] 5,25" aygıtları kurma

**A** Install 1x 5.25" optical drive


**B** Install 2x 5.25" optical drive




**B1**




**B2**




**B3**




**B4**





**B5**



**B6**













## 7



- EN** How to install 3.5" devices
- AR** كيفية تثبيت القرص الصلب مقاس 3.5" بوصة
- BG** Как се инсталират 3.5" устройствата
- CHS** 安装3.5"装置
- CHT** 安裝3.5"裝置
- CS** Jak nainstalovat zařízení 3.5"
- DE** So installieren Sie 3,5 Zoll Geräte
- EL** Πώς να εγκαταστήσετε τις συσκευές 3.5"
- ES** Como instalar los dispositivos de 3.5"
- FA** نحوه نصب درایوهای 3.5 اینچ
- FR** Comment installer les périphériques 3.5 pouces

- HU** 3.5" eszközök beszerelése
- ID** Cara memasang perangkat 3.5
- IT** Come installare le unità da 3.5"
- JP** 3.5インチデバイス (HDDなど) の取り付け方法
- KR** 3.5인치 하드 디스크 드라이브 설치 방법
- NL** Installeren van de 3.5" apparaten
- PL** Jak zamontować urządzenia 3.5 "
- PT** Como instalar os dispositivos de 3,5"
- RU** Как установить 3,5" устройства
- SR** Kako da instalirate 3,5" uređaje
- TR** 3,5" aygıtları kurma











**8**


- [EN] How to install 2.5" devices
- [AR] كيفية تثبيت القرص الصلب مقاس 2.5 بوصة
- [BG] Как се инсталират 2.5" устройствата
- [CHS] 安裝2.5"裝置
- [CHT] 安裝2.5"裝置
- [CS] Jak nainstalovat zařízení 2.5"
- [DE] So installieren Sie 2,5 Zoll Geräte
- [EL] Πως να εγκαταστήσετε τις συσκευές 2.5"
- [ES] Como instalar los dispositivos de 2.5"
- [FA] نحوه نصب درایوهای 2.5 اینچ
- [FR] Comment installer les périphériques 2.5 pouces

- [HU] 2.5" eszközök beszerelése
- [ID] Cara memasang perangkat 2.5"
- [IT] Come installare le unità da 2.5"
- [JP] 2.5インチデバイス (SSDなど) の取り付け方法
- [KR] 2.5인치 하드 디스크 드라이브 설치 방법
- [NL] Installeren van de 2.5" apparaten
- [PL] Jak zamontować urządzenia 2.5"
- [PT] Como instalar os dispositivos de 2,5"
- [RU] Как установить 2,5" устройства
- [SR] Kako da instalirate 2,5" uređaje
- [TR] 2,5" aygıtları kurma






**A** Installation behind motherboard tray

**B** Installation on M.Port





OR



9





- [EN]** How to install case fans and radiators
- [AR]** كيفية تركيب المراوح و المبرد
- [BG]** Как се инсталират радиатори и вентилатори
- [CHS]** 安裝風扇和水冷排
- [CHT]** 安裝風扇和水冷排
- [CS]** Jak nainstalovat ventilátory a chladiče
- [DE]** So installieren Sie Lüfter und Radiatoren
- [EL]** Πώς να εγκαταστήσετε ανεμιστήρες και ψυγεία
- [ES]** Como instalar ventiladores de caja y radiadores
- [FA]** نحوه نصب رادیاتورها و فن‌های کیس
- [FR]** Comment installer les ventilateurs et radiateurs



- [HU]** Ventilátorok és a radiátorok beszerelése
- [ID]** Cara memasang kipas kasus dan radiator
- [IT]** Come Installare ventole e radiatori
- [JP]** ケースファンとラジエーターの取り付け方法
- [KR]** 케이스 팬 및 라디에이터 설치 방법
- [NL]** Installeren van de ventilatoren en radiatoren
- [PL]** Jak zamontować wentylatory i radiatory
- [PT]** Como instalar as ventoinhas e os radiadores
- [RU]** Как установить корпусные вентиляторы и радиаторы
- [SR]** Kako da instalirate ventilatore i radijatore
- [TR]** Kasa fanlarını ve radyatörleri takmak

## A Install on top

## B Install in front

## C Install in bottom










## 10


- EN** How to install 420mm radiator
- AR** كيفية تركيب المراو 420mm المبرد
- BG** Как да инсталирате 420 мм радиатор
- CHS** 安裝420mm水冷排
- CHT** 安裝420mm水冷排
- CS** Jak nainstalovat chladič o průměru 420 mm
- DE** So installieren Sie 420mm Radiator
- EL** Πώς να εγκαταστήσετε ψυγείο 420mm
- ES** Cómo instalar un radiador de 420mm
- FA** نحوه نصب رادیاتور 420 میل‌متری
- FR** Comment installer un radiateur de 420 mm

- HU** 420mm radiátor felszerelése
- ID** Cara memasang radiator 420mm
- IT** Come installare radiatore da 420mm
- JP** 420mmラジエーターの取り付け方法
- KR** 420mm 라디에이터 설치 방법
- NL** Installeren van de 420mm radiator
- PL** Jak zainstalować chłodnicę 420 mm
- PT** Como instalar o radiador de 420mm
- RU** Как установить радиатор 420 мм
- SR** Kako da instalirate 420mm radijator
- TR** 420mm Radyatörü takmak






## Fan



## Radiator





	Position	Support
<b>Fan</b>	Top	120/140mm x 3
	Front	120/140mm x 3
	Bottom*	120/140mm x 2
<b>Radiator</b>	Top	120mm, 140mm, 240mm, 280mm, 360mm/420mm (requires removal of 5.25" Optical drive Cage)
	Front	120mm, 140mm, 240mm, 280mm, 360mm, 420mm (requires removal of 5.25" Optical drive Cage)
	Bottom*	120mm, 140mm, 240mm, 360mm (requires alternative PSU location)

For all 3 positions it requires the purchase of an additional cooling bracket.

## 11





- [EN] How to install radiator in the rear
- [AR] كيفية تركيب المبرد في الخلف
- [BG] Как се инсталира радиатор в задния панел
- [CHS] 安装后方的水冷排
- [CHT] 安裝後方的水冷排
- [CS] Jak nainstalovat chladič vzadu
- [DE] So installieren Sie einen Radiator am Heck
- [EL] Πώς να εγκαταστήσετε ψυγείο στο πίσω μέρος
- [ES] Como instalar el radiador en a parte posterior
- [FA] نحوه نصب رادیاتور در قسمت پشتی
- [FR] Comment installer le radiateur à l'arrière
- [HU] Radiátor beszerelésé hátulra
- [ID] Cara memasang radiator bagian belakang
- [IT] Come installare un radiatore nella sezione posteriore
- [JP] 後部にラジエーター 取り付け方法
- [KR] 뒤쪽에 라디에이터를 설치하는 방법
- [NL] Installeren van de radiator aan de achterkant
- [PL] Jak zamontować radiator na tylnej ścianie
- [PT] Como instalar o radiador na traseira
- [RU] Как установить радиатор в задней части корпуса
- [SR] Kako instalirati radiator u zadnjem delu
- [TR] Radyatörü arkaya takmak



## 12

- [EN] Cable management
- [AR] تنظيم الأسلاك
- [BG] Кабел мениджмънт
- [CHS] 线缆整理
- [CHT] 線纜整理
- [CS] Cable management
- [DE] Kabel-management
- [EL] Διαχείριση καλωδίων
- [ES] Gestión de cable
- [FA] مدیریت کابل
- [FR] Gestion des câbles
- [HU] Kábel menedzsment
- [ID] Manajemen Kabel
- [IT] Cable Management
- [JP] 配線収納
- [KR] 케이블 관리
- [NL] Kabel management
- [PL] Zarządzanie kablami
- [PT] Gestão de cabos
- [RU] Кабель менеджмент
- [SR] Pozicioniranje kablova
- [TR] Kablo Yönetimi





## 13

**EN** Completing installation

**AR** استكمال التثبيت

**BG** Завършване на инсталацията

**CHS** 完成組裝

**CHT** 完成組裝

**CS** Dokončení instalace

**DE** So schliessen Sie die Installation ab

**EL** Ολοκλήρωση εγκατάστασης

**ES** Completar la instalación

**FA** تکمیل نصب

**FR** Terminer l'installation

**HU** A szerelés befejezése

**ID** Menyelesaikan Instalasi

**IT** Completamento dell'installazione

**JP** 完成図

**KR** 설치 완료

**NL** Installatie voltooid



**PL** Kończenie instalacji

**PT** Finalizar a instalação


**RU** Завершение сборки

**SR** Dovršavanje instalacije

**TR** Kurulum tamamlanıyor



**Fan & A-RGB controller operation** / Lüfter und A-RGB Steuerung / Funcionamiento del ventilador y del controlador A-RGB / Fonctionnement du contrôleur d'éclairage A-RGB et de ventilateurs / Funcionamento del controller Ventola& A-RGB / Obsługa kontrolera wentylatorów i podświetlenia A-RGB / Управление контроллера вентилятора и A-RGB / Как функционира контролер вентилатор и A-RGB / Ovládání ventilátoru a A-RGB / Χρήση ελεγκτή fan & A-RGB / Ventilátor és A-RGB vezérlő kezelése / Ventilator & A-RGB controller bediening / Funcionamento do controlador das ventoinhas e A-RGB / Funkcija ventilatora i A-RGB kontrolera / Fan & A-RGB kontrolcü işlemleri / 風扇和A-RGB燈光控制操作 / 風扇和A-RGB灯光控制操作 / ファンとA-RGBコントローラー操作説明 / Pengontrol operasional kipas danA-RGB / 팬 및 A-RGB 컨트롤러 작동 / متحكم المراوح و إضاءة A-RGB / A-RGB / عملکرد کنترلر فن و




	Mode	Description
(✳) Fan controller	(H) High	Fan operates at 100%
	(M) Medium	Fan operates at 75%
	(L) Low	Fan operates at 50%
	(↑ ↓) M/B sync	Motherboard sync (PWM input)
(☼) Addressable RGB controller	(☼) Static	7 preset colors
	(🔄) Cycle	4 preset dynamic color cycles
	(↑ ↓) M/B sync*	Sync up with motherboard lighting

\*M/B sync mode only works when connecting control board to motherboard A-RGB header. Do NOT connect to regular RGB header!

## Control Board Layout / Layout der Steuerplatine / Diseño de la tarjeta de control / Disposition de la carte de contrôle / Layout della scheda di controllo / Układ panelu sterowania / Панель управления / Карта на контролния панел / Rozložení ovládací desky / Διάταξη του control board / Kezelő lap kiosztása / Ventilator & RGB aansluit schema / Layout do kontrolador da board / Šema kontrolne ploče / Kontrol kartı şeması / 控制板接口 / 控制板接口 / コントロールボードレイアウト / Susunan Papan Kontrol / 컨트롤 보드 레이아웃 / طرح مدار کنترل / لوحة التحكم

طرح مدار کنترل / لوحة التحكم



	Connector Name	Description
A	SATA power connector	2 x SATA 15-pin power connectors are required to provide power input to the control board (1)
B	Front panel control connector	Connects to IO panel
C	A-RGB Lighting connector	Total 4 channels,max 2A output per channel, total 8A output for all A-RGB out put (2)
D	MB A-RGB sync connector	Connect to motherboard A-RGB sync port
E	USB connector	Connect to motherboard USB2.0 port for controller Firmware upgrade
F	MB FAN sync connector	Connect to motherboard FAN port
G	Fan Connectors	FAN1~FAN6 4pin PWM FAN connector(compatible with 3pin FAN),0.4A output channel and 2.4A total





(1) Minimum 18AWG thickness PSU wires required as current may exceed 6A.

(2) 3 channels for pre-installed lighting on case.






1 channel for additional A-RGB devices. Connect via splitter with SATA to supply power.







## I/O connectors / I/O Anschlüsse / Conectores I/O / Connecteurs E/S / Connettori I/O / Złącza panelu I/O / Разъёмы ввода/вывода / Интерфейсни конектори / Vstup/Výstup / Συνδέσεις I/O / I/O csatlakozók / I/O connectoren / Conectores I/O / I/O konektori / I/O bağılantıları / I/O面板接頭 / I/O面板接头 / I/Oコネクタ / Konektor I/O / I / O 커넥터 / موصلات المنافذ / کنکتورهای I/O







- [EN] Please follow motherboard manual instruction for connection.
- [AR] يرجى اتباع دليل استخدام اللوحة الرئيسية لتثبيت التوصيلات
- [BG] Моля следвайте инструкциите на дънната платка за инсталация
- [CHS] 请遵照主板安装手册进行连接
- [CHT] 請遵照主機板安裝手冊進行連接
- [CS] Pro připojení využijte návod dodaný k základní desce
- [DE] Für die Anschlüsse bitte die Bedienungsanleitung des Mainboards lesen
- [EL] Ακολουθήστε τις οδηγίες την μητρικής κάρτας για την σύνδεση.
- [ES] Siga las instrucciones del manual de la placa base para la conexión.
- [FR] Veuillez vous reporter au manuel de la carte mère pour les instructions de branchement
- [HU] Kövesd az alaplap útmutatóját a helyes csatlakoztatáshoz.
- [ID] Mohon mengikuti instruksi manual motherboard untuk koneksi
- [IT] Seguire le istruzioni della scheda madre per la connessione.
- [JP] マザーボードの取り付け方法
- [KR] 연결을 위해 마더보드 매뉴얼 지시를 따르십시오.
- [NL] Volg de handleiding van het moederbord voor installatie
- [PL] Przy podłączaniu kieruj się instrukcją obsługi płyty głównej
- [PT] Por favor siga o manual da motherboards para as conexões
- [RU] Для подключения, пожалуйста, следуйте инструкциям материнской платы.
- [SR] Molimo vas da pratite uputstva matične ploče za povezivanje.
- [TR] Bağlantılar için lütfen anakart kullanma kılavuzuna bakınız







Case Connector
USB 3.0 connector

USB 3.1 connector

HD Audio connector

Power SW/ LED,HDD LED Reset SW








**Inverse layout adjustment** / Anpassung des Layouts: Montage auf der gegenüberliegenden Seite / Ajuste de disposición inverso / Réglage de la disposition inversée / Regolazione inversa del layout / Dostosowanie odwrotnego układu / Обратная настройка схемы / Възможност за множество ориентации на дънната платка / Inverzní rozložení / Ρύθμιση αντίστροφης διάταξης / Fordított kiosztás beállítása / Aanpassingen voor gespiegelde opstelling / Ajustamento inverso de layout / Rotiranje i podešavanje rasporeda konstrukcije / Ters düzen ayarlaması / 倒轉配置調整 / 倒置(180度翻轉)調整 / インバースレイアウト調整 / Pengaturan tata letak terbalik / 역 레이아웃 조정 / تعديل التخطيط العكسي / بیکربندی طرح معکوس



























**Chimney effect layout adjustment** / Anpassung des Layouts: Kamin-Effekt / Ajuste de la disposición del efecto chimenea / Réglage de la disposition avec effet de cheminée / Regolazione del layout dell'effetto camino / Dostosowanie układu typu efekt kominowy / Регулировка эффекта образования тяги / Възможност за инсталация тип комин / Uspořádání využívající kominový efekt / Ρύθμιση διάταξης φυσικού ελκυσμού / Kémény effektus kiosztás beállítása / Aanpassingen aan de indeling voor Chimney effect / Ajustamento de layout efeito chaminé / Pozicioniranje rasporeda konstrukcije radi efikasnog prenosa toplote "Efekat dimnjaka" / Baca etkisi düzeni ayarı / 煙囪效應配置調整 / 垂直風道(90度旋轉)調整 / 煙突効果レイアウト調整 / Pengaturan tata letak efek cerobong asap / 굴뚝 효과 레이아웃 조정 / تعديل مخطط تأثير المدخنة / بيكريندى طرح «اثر دودکش»











**Make It Yours.**

Asia Pacific - Cooler Master Technology Inc.  
8F., No. 788-1, Zhongzheng Rd., Zhonghe Dist.,  
New Taipei City 23586, Taiwan (R.O.C.).  
Tel: +886-2-2225-3517

China - Cooler Master China  
Room 2062, Floor 6, No. 421, Weiqing Rd.,  
Jinshan District, Shanghai City, China  
Tel: +86-21-51872177

Europe - Cooler Master Europe B.V.  
Lodewijkstraat 1b, 5652AC Eindhoven, The Netherlands  
Tel: +31-(0)40-702-0900

North America - Cooler Master NA  
2929 E Imperial Hwy., Suite #110, Brea, CA 92821  
Tel: +1-888-624-5099

South America  
E-mail: [Soporte\\_Latam@coolermaster.com.tw](mailto:Soporte_Latam@coolermaster.com.tw)




**Product Page**

[www.coolermaster.com/case/full-tower/  
cosmos-c700m](http://www.coolermaster.com/case/full-tower/cosmos-c700m)



**Technical Support**

[account.coolermaster.com](mailto:account.coolermaster.com)

512001811-GP Ver 2.0: 2018/12 

The color and specification are subject to be changed without further notification.  
Please visit our website for updated information: [www.coolermaster.com](http://www.coolermaster.com)

©2018 Cooler Master Technology Inc. All Rights Reserved. All trademarks are registered to their respective owners.

Ovaj dokument je originalno proizveden i objavljen od strane proizvođača, brenda Cooler Master, i preuzet je sa njihove zvanične stranice. S obzirom na ovu činjenicu, Tehnoteka ističe da ne preuzima odgovornost za tačnost, celovitost ili pouzdanost informacija, podataka, mišljenja, saveta ili izjava sadržanih u ovom dokumentu.

Napominjemo da Tehnoteka nema ovlašćenje da izvrši bilo kakve izmene ili dopune na ovom dokumentu, stoga nismo odgovorni za eventualne greške, propuste ili netačnosti koje se mogu naći unutar njega. Tehnoteka ne odgovara za štetu nanесenu korisnicima pri upotrebi netačnih podataka. Ukoliko imate dodatna pitanja o proizvodu, ljubazno vas molimo da kontaktirate direktno proizvođača kako biste dobili sve detaljne informacije.

Za najnovije informacije o ceni, dostupnim akcijama i tehničkim karakteristikama proizvoda koji se pominje u ovom dokumentu, molimo posetite našu stranicu klikom na sledeći link:

<https://tehnoteka.rs/p/cooler-master-kuciste-cosmos-c700m-mcc-c700m-mg5n-s00-akcija-cena/>